


## Butterfly control & isolation valve with extended control range with DeviceNet interface

### Series 616 DN 40-100 mm (I.D. 1.5" - 4")

This manual is valid for the valve ordering number(s):

616 . . . . .GQ - . . . . .	(2 sensor inputs / analog outputs)
616 . . . . .AQ - . . . . .	(2 sensor inputs / analog outputs / $\pm 15V$ SPS)
616 . . . . .HQ - . . . . .	(2 sensor inputs / analog outputs / PFO)
616 . . . . .CQ - . . . . .	(2 sensor inputs / analog outputs / $\pm 15V$ SPS / PFO)

SPS = Sensor Power Supply    PFO = Power Failure Option



Sample Picture

## Imprint

Manufacturer VAT Vakuumentile AG, CH-9469 Haag, Switzerland

Website: [www.vatvalve.com](http://www.vatvalve.com)

Phone: +41 81 771 61 61

Fax: +41 81 771 48 30

Email: [CH@vatvalve.com](mailto:CH@vatvalve.com)

Publisher VAT Vakuumentile AG, CH-9469 Haag, Switzerland

Editor VAT Vakuumentile AG, CH-9469 Haag, Switzerland

Print VAT Vakuumentile AG, CH-9469 Haag, Switzerland

Copyright © VAT Vakuumentile AG 2022

No part of these instructions may be reproduced in any way (photocopies, microfilms or any other reproduction processes) nor may it be manipulated with electronic systems, duplicated or distributed without written permission from VAT. Offenders are liable to pay damages.

The original VAT firmware and updated state of the art versions of the VAT firmware are intended for use with VAT products. The VAT firmware contains a limited, time unlimited user license. The VAT firmware may not be used for purposes other than those intended nor is it permitted to make copies of the VAT firmware. In particular, it is strictly forbidden to give copies of the VAT firmware to other people.

The use of trade names, brand names, trademarks, etc. in these Instructions does not entitle third parties to consider these names to be unprotected and to use them freely. This is in accordance with the meaning of the laws and acts covering brand names and trademarks.

## Contents

<b>1</b>	<b>Description of product.....</b>	<b>6</b>
1.1	Identification of product .....	6
1.2	Firmware .....	6
1.3	Use of product .....	6
1.4	Used abbreviations.....	6
1.5	Related documents.....	6
1.6	Important information.....	6
1.7	Technical data .....	7
1.7.1	Control and actuating unit .....	7
1.7.2	Valve unit .....	7
<b>2</b>	<b>Safety .....</b>	<b>8</b>
2.1	Compulsory reading material.....	8
2.2	Danger levels .....	8
2.3	Personnel qualifications.....	9
2.4	Safety labels .....	9
<b>3</b>	<b>Design and Function.....</b>	<b>10</b>
3.1	Design .....	10
3.2	Function.....	11
3.2.1	Pressure control system overview and function .....	11
3.2.2	Principle of a pressure control system .....	12
<b>4</b>	<b>Installation .....</b>	<b>13</b>
4.1	Initial procedure .....	13
4.2	Unpacking .....	14
4.3	Installation into the system .....	15
4.3.1	Installation Hints.....	16
4.3.2	Installation space condition .....	16
4.3.3	Admissible forces .....	17
4.3.4	Admissible forces at controller .....	18
4.3.5	Tightening torque DN <sub>s</sub> 40 – 50mm .....	19
4.3.6	Tightening torque DN <sub>s</sub> 63 – 100mm .....	20
4.4	Connection overview .....	21
4.5	Power-, Ground- and Sensor Connection.....	22
4.5.1	Connection cable recommendations.....	22
4.5.2	Ground connection.....	23
4.5.3	Power and Sensor supply concepts.....	24
4.5.4	Drive Power Enabled Switch, Safety Mode.....	28
4.6	Power Up.....	29
4.7	Power Down, Power Failure Option .....	29
4.7.1	Power down behavior in case of power failure .....	29
4.7.2	Power Fail Option .....	29
4.8	Service Port, CPA software .....	30
4.8.1	How to start.....	30
4.8.2	Update .....	31
4.9	Display Information.....	32
4.9.1	Power up.....	32
4.9.2	Operation .....	33
4.9.3	Error .....	33
4.10	System Settings and States .....	34
4.10.1	Identification.....	34
4.10.2	Statistics.....	35
4.10.3	Warning/Error.....	36
4.10.4	Service.....	36


4.11	Valve Settings and States.....	37
4.11.1	States .....	37
4.11.2	Homing.....	37
4.11.3	Cycle Counter.....	38
4.11.4	Position Restriction.....	38
4.11.5	Position Adaption .....	39
4.12	Interface DeviceNet .....	40
4.12.1	Introduction .....	41
4.12.2	EDS File .....	41
4.12.3	Messaging Format.....	42
4.12.4	Objects .....	43
4.12.5	Identity Object (Class ID 1) .....	44
4.12.6	Device Net Object (Class ID 3).....	44
4.12.7	Assembly Object (Class ID 4).....	44
4.12.8	Discrete Input Object (Class ID 8).....	47
4.12.9	S-Device Supervisor Object (Class ID 48) .....	48
4.12.10	S-Analog Sensor Object (Class ID 49).....	50
4.12.11	S-Single Stage Controller Object (Class ID 51).....	52
4.12.12	Refer to «Adaptive algorithm.....	53
4.12.13	Note: Refer to «Adaptive algorithm .....	54
4.12.14	Pressure Controller Object (Class ID 100) .....	56
4.13	Pressure Sensor.....	59
4.13.1	Mechanical connection requirements .....	59
4.13.2	Configuration.....	60
4.13.3	Crossover (2 sensor operation mode).....	62
4.13.4	Zero Adjust.....	63
4.13.5	Logarithmic Pressure .....	64
4.14	Power Connector Digital IO .....	65
4.14.1	Digital Input .....	65
4.14.2	Digital Output.....	66
<b>5</b>	<b>Operation.....</b>	<b>67</b>
5.1	Access Mode .....	68
5.1.1	Overview .....	68
5.1.2	Remote and Locked operation .....	68
5.1.3	Local operation.....	68
5.2	Control Mode .....	69
5.2.1	View .....	70
5.3	Pressure Control.....	71
5.3.1	Controller units .....	71
5.3.2	Control algorithm.....	72
5.3.3	Adaptive algorithm.....	74
5.3.4	PI algorithm .....	85
5.3.5	Pressure Ramp .....	91
5.3.6	Profile Ramp .....	94
5.3.7	Automated Controller Selector .....	97
5.3.8	Control Position Restriction.....	98
5.3.9	Store Control Parameter Volatile.....	98
5.4	Position Control .....	99
5.4.1	Parameter .....	99
5.4.2	Position Ramp.....	99
5.5	Operation under increased temperature .....	100
<b>6</b>	<b>Trouble shooting .....</b>	<b>101</b>
6.1	Warnings .....	101
6.2	Errors.....	103
6.2.1	Error Recovery .....	103
6.2.2	Error Bitmap .....	103
6.2.3	Error Number.....	104

6.2.4	Error Code .....	104
6.3	Troubleshooting List .....	106
<b>7</b>	<b>Maintenance .....</b>	<b>107</b>
7.1	Maintenance intervals.....	107
7.2	Maintenance procedures .....	108
7.2.1	Replacement of vulcanized plate or plate with O-ring .....	109
7.2.2	Replacement of shaft feed through seals and valve cleaning .....	113
7.2.3	Replacement of Option board .....	119
<b>8</b>	<b>Repairs .....</b>	<b>124</b>
8.1	FPR Service .....	124
<b>9</b>	<b>Dismounting and Storage.....</b>	<b>125</b>
9.1	Dismounting .....	125
9.2	Storage.....	126
<b>10</b>	<b>Packaging and Transport .....</b>	<b>127</b>
10.1	Packaging.....	128
10.2	Transport.....	128
<b>11</b>	<b>Disposal .....</b>	<b>129</b>
<b>12</b>	<b>Spare parts .....</b>	<b>130</b>
12.1	ISO-KF for DN's 40 - 63mm .....	131
12.1.1	Drawing.....	131
12.1.2	ISO-KF valve unit – aluminum hard anodized, without heating.....	132
12.1.3	ISO-KF valve unit – stainless steel, without heating .....	132
12.1.4	Seals and grease.....	133
12.1.5	Clamping connections for ISO-KF.....	133
12.2	ISO-F for DN's 80 - 100mm.....	134
12.2.1	Drawing.....	134
12.2.2	ISO-F valve unit – aluminum hard anodized, without heating .....	135
12.2.3	ISO-F valve unit – stainless steel, without heating.....	135
12.2.4	Seals and grease .....	136
12.3	Control unit and Accessories.....	137
12.3.1	Control and actuating unit .....	137
12.3.2	Accessories.....	137
12.3.3	Centering ring with VITON® O-ring.....	137

# 1 Description of product

## 1.1 Identification of product

The fabrication number and order number are fixed on the product directly or by means of an identification plate.



## 1.2 Firmware

Please look up the firmware version in the CPA or read it from the display at start up.  
 Location: CPA/Parameters: System.Identification.Firmware

## 1.3 Use of product

This product is a Butterfly control valve for downstream pressure control in vacuum systems. Use product for clean and dry vacuum applications only. Other applications are only allowed with the written permission of VAT.

## 1.4 Used abbreviations

Abbreviation	Description
CPA	Control Performance Analyzer
PFO	Power Failure Option
SFS	Sensor Full Scale
SPS	Sensor Power Supply
ADC	Analog-to-digital converter

## 1.5 Related documents

- Product Data Sheet
- Dimensional Drawing
- IOMI Heating device (if valve with heater)

## 1.6 Important information



This symbol points to a very important statement that requires particular attention.

### Example:



Refer to chapter: «Technical data» for detailed information.

## 1.7 Technical data

### 1.7.1 Control and actuating unit



See product data sheet.

### 1.7.2 Valve unit



See product data sheet.

## 2 Safety

### 2.1 Compulsory reading material

Read this chapter prior to performing any work with or on the product. It contains important information that is significant for your own personal safety. This chapter must have been read and understood by all persons who perform any kind of work with or on the product during any stage of its serviceable life.

	NOTICE
	<p><b>Lack of knowledge</b> Failing to read this manual may result in property damage. Firstly, read manual.</p>



These Installation, Operating & Maintenance Instructions are an integral part of a comprehensive documentation belonging to a complete technical system. They must be stored together with the other documentation and accessible for anybody who is authorized to work with the system at any time.

### 2.2 Danger levels

	⚠ DANGER
	<p><b>High risk</b> Indicates a hazardous situation which, if not avoided, will result in death or serious injury.</p>


	⚠ WARNING
	<p><b>Medium risk</b> Indicates a hazardous situation which, if not avoided, could result in death or serious injury.</p>

	⚠ CAUTION
	<p><b>Low risk</b> Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury.</p>


	NOTICE
	<p><b>Command</b> Indicates a hazardous situation which, if not avoided, may result in property damage.</p>



## 2.3 Personnel qualifications


	<b>⚠ WARNING</b>	
	<b>Unqualified personnel</b> Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.	

## 2.4 Safety labels


Label	Part No.	Location on valve
	T-9001-156	On protective foil covering of valve opening

### 3 Design and Function

#### 3.1 Design




- |   |            |   |             |
|---|------------|---|-------------|
| 1 | Controller | 4 | Double seal |
| 2 | Coupling   | 5 | Plate       |
| 3 | Bearing    | 6 | Body        |



XY: Double excentric bearing: prevents wearing of the O-ring and particle generation


### 3.2 Function

The valve plate acts as a throttling element and varies the conductance of the valve opening. The integrated controller calculates the required plate position to achieve the setpoint pressure. Actuation is handled by a stepper motor with an encoder for position monitoring. This principle ensures fast and accurate process pressure control even in demanding contaminating processes. The seal being attached to the plate reduces the minimum controllable conductance and allows leak tight closing of the valve. In closed position, the seal is pressed against the body.



#### 3.2.1 Pressure control system overview and function

Vacuum pressures are always absolute pressures unless explicitly specified as pressure differences.



### 3.2.1.1 Way of operation

The controller compares the actual pressure in the process chamber given by the pressure sensor with the preset pressure. The controller uses the difference between actual and set pressure to calculate the correct position of the control valve. The controller drives the control valve into the correct position and the actual pressure again equals the set pressure. This control operation is performed continuously. Pressure changes in the process chamber due to leaks, desorption, and gas flow, reaction products, variations in pumping speed etc. are always corrected at once.

### 3.2.1.2 Pressure control


In a vacuum system which is pumped and into which gas is admitted at the same time, the pressure can be controlled in two ways:

1. Downstream control (standard):  
The pressure is controlled by changing the conductance of a control valve between pump and process chamber. This changes the effective pumping speed at the process chamber. Pressure and gas flow can be independently controlled over a wide range.
2. Upstream control:  
The pressure is controlled by changing the gas flow into the process chamber, while the pumping speed remains constant.

### 3.2.1.3 Adaptive controller (standard)

A controller adapting itself to changes in pressure, gas flow and pumping speed without any manual adjustments. This allows for a completely automatic operation of the system.


## 3.2.2 Principle of a pressure control system




## 4 Installation


	⚠ WARNING
	<p><b>Unqualified personnel</b>                  Inappropriate handling may cause serious injury or property damage.                  Only qualified personnel are allowed to carry out the described work.</p>

### 4.1 Initial procedure



## 4.2 Unpacking

	<b>NOTICE</b>
	<p><b>Physical overstraining at controller</b> Inappropriate handling with the valve may cause in damage of controller. Do not place the valve on the controller.</p>

	<b>NOTICE</b>
	<p><b>Physical overstraining at pedestal</b> Inappropriate handling with the valve may cause in damage of pedestal. Lift valve at valve body out of transport case.</p>





- Make sure that the supplied products are in accordance with your order.
- Inspect the quality of the supplied products visually. If it does not meet your requirements, please contact VAT immediately.
- Store the original packaging material. It may be useful if products must be returned to VAT.


1. Open the transport case and remove inside packing material as far as necessary.
2. Lift the valve carefully and place it on a clean place.





Do not remove protective foils from valve opening


### 4.3 Installation into the system

	 <b>WARNING</b>
	<p><b>Valve opening</b> Risk of serious injury. Human body parts must be kept out of the valve opening and away from moving parts. Do not connect the controller to power before the valve is installed complete into the system.</p>

	<b>NOTICE</b>
	<p><b>Sealing surfaces</b> Sealing surfaces of valve and vacuum system could be damage in case of incorrect handling. Only qualified personal are allowed to install the valve into the vacuum system.</p>

	<b>NOTICE</b>
	<p><b>Wrong connection</b> Wrong connection may result in damage of controller or power supply. Connect all cables exactly as shown in the following descriptions and schematics.</p>

	<b>NOTICE</b>
	<p><b>Burned connector pins (spark)</b> Connector pins or electronic parts could damage, if plugged and unplugged under power. Do not plug or unplug connectors under power.</p>

	<b>NOTICE</b>
	<p><b>Contamination</b> Gate and other parts of the valve must be protected from contamination. Always wear clean room gloves when handling the valve.</p>



Mount valve to a clean system only.

### 4.3.1 Installation Hints

Install valve into the vacuum system. Valve seat side shall face process chamber.




- Do not tighten the flange screws stronger than indicated under chapter «Tightening torque».
- Do not admit higher forces to the valve than indicated under chapter «Admissible forces».
- Make sure that enough space is kept free to do preventive maintenance work. The required space is indicated on the dimensional drawing.
- Control unit of valves with ISO-KF (616 . . – K . . .) needs support when mounted on horizontal piping and control unit does not hang.

### 4.3.2 Installation space condition



Install the valve with integrated controller with space for dismantling and air circulation as shown in figure below.



Sample picture



### 4.3.3 Admissible forces


<b>NOTICE</b>	
	<p><b>Force at valve body</b></p> <p>Forces from the weight of other components can lead to deformation of the valve body and to malfunction of the valve.</p> <p>Do not higher force the valve body as specified.</p>



The following forces are admissible.


Valve size		Axial tensile or compressive force «F <sub>A</sub> »		Bending moment «M»		
mm	inch	N	lb.	Nm	lbf.	
40	1½	100	22	6	4.5	<p>Sample picture</p>
50	2	150	34	11	8	
63	2½	800	176	32	24	<p>sample picture</p>
80	3	850	187	35	26.5	
100	4	1000	220	40	30	

4.3.4 Admissible forces at controller

<b>NOTICE</b>	
	<p><b>Force at pedestal</b></p> <p>In case higher force is applied, the pedestal could be permanently damaged.</p> <ul style="list-style-type: none"> <li>- Do not pushing, shocking load, or stressing the valve controller</li> <li>- Do not deposit anything at valve controller</li> </ul>



The admissible force at valve controller in regards to the pedestal is shown in table below



Admissible force «F»	Overview F = Force a = middle of aluminum part of controller (b / 2)
<b>400 N</b>	 <p style="text-align: left; margin-top: 10px;">sample pictures</p>

### 4.3.5 Tightening torque DN40 – 50mm



Tightening torques for ISO-KF flange connections depend on the type of seal which is used. Follow recommendations of seal manufacturer.

#### 4.3.5.1 ISO-KF Clamping connections

Clamping chain (example)

Valve size	ISO-KF	ISO-KF	 e.g.: 31032-KASA-0001 31034-KASA-0001	
	recommended tightening torque (Nm)	recommended tightening torque (lbs . ft)		
DN40 / 1½ "	5	3.7		
DN50 / 2"	6	4.5		

Clamping device (example)

Valve size	ISO-KF	ISO-KF	 e.g.: 31032-KASE-0001 31034-KASE-0001	
	recommended tightening torque (Nm)	recommended tightening torque (lbs . ft)		
DN40 / 1½ "	12	9		
DN50 / 2"	12	9		

### 4.3.6 Tightening torque DN63 – 100mm


Tighten mounting screws of the flanges uniformly in crosswise order. Observe the maximum torque levels in the following table. Higher tightening torques deforms the valve body and may lead to malfunction of the valve.

#### 4.3.6.1 Mounting of CF-F flanges

Tightening torques for CF-F flange connections depend on the type of seal which is used. Follow recommendations of seal manufacturer.

#### 4.3.6.2 Mounting with centering rings


Valve size	ISO-F	ISO-F
	max. tightening torque (Nm)	max. tightening torque (lbs . ft)
DN63 / 2½ "	8-10	6-8
DN80 / 3"	8-10	6-8
DN100 / 4"	8-10	6-8
	hole depth (mm)	hole depth (inch)
DN63 / 2½ "	12	0.47
DN80 / 3"	12	0.47
DN100 / 4"	12	0.47




Refer to «Spare parts / Accessories» for centering rings ordering numbers.

#### 4.3.6.3 Mounting with O-ring in grooves



Valve size	ISO-F	JIS	ASA-LP	ISO-F	JIS	ASA-LP
	max. tightening torque (Nm)			max. tightening torque (lbs . ft)		
DN63 / 2½ "	20-23	35-40	35-40	15-17	26-30	26-30
DN80 / 3"	20-23	35-40	35-40	15-17	26-30	26-30
DN100 / 4"	20-23	35-40	35-40	15-17	26-30	26-30
	hole depth (mm)			hole depth (inch)		
DN63 / 2½ "	12	n/a	n/a	0.47	n/a	n/a
DN80 / 3"	12	n/a	n/a	0.47	n/a	n/a
DN100 / 4"	12	n/a	n/a	0.47	n/a	n/a





Make sure that screws in use are capable to withstand applied torques.

### 4.4 Connection overview

#### Controller IC2-H3:





#### System:



- 1 Valve
- 2 Process chamber
- 3 Gas inlet
- 4 Pressure sensor(s)
- 5 Sensor cable(s)
- 6 Controller and actuator
- 7 Cable to remote control unit
- 8 Cable to power supply
- 9 Pump

## 4.5 Power-, Ground- and Sensor Connection

	NOTICE
	<p><b>Wrong connection</b></p> <p>Wrong connection may result in damage of controller or power supply. Connect all cables exactly as shown in the following descriptions and schematics.</p>

	NOTICE
	<p><b>Burned connector pins (spark)</b></p> <p>Connector pins or electronic parts could damage, if plugged and unplugged under power. Do not plug or unplug connectors under power.</p>

### 4.5.1 Connection cable recommendations

For Power Supply connection cables, VAT recommends:


Class (min.)	L (Length max.)	d (diameter)
AWG18 (shielded)	5 m	0.823 mm <sup>2</sup>

For Sensor & Signal connection cables, VAT recommends:


Class (min.)	L (Length max.)	d (diameter)
AWG22 (shielded)	20 m	0.326 mm <sup>2</sup>

#### 4.5.2 Ground connection

Recommendation for ground connection between controller and system chassis with cable or with ground strap.



- Recommendation for ground connection cable: AWG 12 (4 mm<sup>2</sup>)
- The connection point at chassis (FE) must be blank metal (not coated).



- Connection plates of ground strap must be total plane for a good electrical contact!
- The connection point at chassis (FE) must be blank metal (not coated). It is also possible to connect the ground strap at system chamber if it is well connected to PE.
- Avoid low chassis cross section to the system PE connection. (min. same cross section as ground strap)

### 4.5.3 Power and Sensor supply concepts

This valve offers 3 alternative concepts to supply the sensor(s) with power. This depends on the sensor type and valve version that is used.

Concepts:

#### 24 VDC sensors:

- External +24 VDC supplied to POWER connector is feedthrough to SENSOR connector. Refer to chapter «Power and sensor connection (+24 VDC sensors) ».

#### ±15 VDC sensors:

- External ±15 VDC supplied to POWER connector is feedthrough to SENSOR connector. Refer to chapter «Power and sensor connection (±15 VDC sensors) without optional SPS module».
- External +24 VDC supplied to POWER connector is converted into ±15 VDC by the valve internal SPS and supplied to SENSOR connector. Refer to chapter «Power and sensor connection (±15 VDC sensors) with optional SPS module».



This concept is only possible when Sensor Power Supply (SPS) option is installed.

For max load consumption, refer to chapter «Technical Data – Control and actuating unit».

Valve versions:

- 616 . . . . **G** . . . . . / 616 . . . . **T** . . . . . / 616 . . . . **H** . . . . .      SPS module not included
- 616 . . . . **A** . . . . . / 616 . . . . **C** . . . . .      SPS module included




The SPS module can be retrofitted.  
Refer to chapter Retrofit / replacement procedure for instruction.



4.5.3.1 Power and 24V sensor connection

[61... G / 61... H versions recommended]



Pins 4 and 11 must be bridged for operation. An optional switch would allow for motor interlock to prevent valve from moving.


Low range sensor may be connected to sensor 1 or sensor 2 input. Do configuration accordingly



- **VAT fuse recommendation: (a) 3 AF**
- Use shielded sensor cable(s). Keep cable as short as possible, but locate it away from noise sources.
- Connector: Use only screws with 4–40 UNC thread for fastening the connectors!

4.5.3.2 Power and 15V sensor connection

[61.....G...../61.....H..... versions recommended]




Pin 4 and 11 must be bridged for operation. An optional switch would allow for motor interlock to prevent valve from moving.

Low range sensor may be connected to sensor 1 or sensor 2 input. Do configuration accordingly.

- VAT fuse recommendation: (a) 3 AF
- Use shielded sensor cable(s). Keep cable as short as possible, but locate it away from noise sources.
- Connector: Use only screws with 4–40 UNC thread for fastening the connectors!

4.5.3.3 Power and 15V sensor connection with optional SPS module

[61... A... / 61... C... versions only]




Pins 4 and 11 must be bridged for operation. An optional switch would allow for motor interlock to prevent valve from moving.

Low range sensor may be connected to sensor 1 or sensor 2 input. Do configuration accordingly.

- VAT fuse recommendation: (a) 3 AF
- Use shielded sensor cable(s). Keep cable as short as possible, but locate it away from noise sources.
- Connector: Use only screws with 4–40 UNC thread for fastening the connectors!

4.5.4 Drive Power Enabled Switch, Safety Mode



- By means of an external switch the motor power supply can be interrupted.
- In this case the valve enters the 'safety mode'.
- This motor interlock prevents the valve from moving (e.g. maintenance work).
- Data reading from the control unit remains possible.
- When motor interlock is active during power up, the valve directly enters the 'safety mode' and is not able to do homing.
- When 'safety mode' is entered from operation (i.e. pressure control mode), the unit will automatically switch to safety control mode and remain at current position. Once motor interlock is deactivated the valve go to control mode 'Init', so a homing is necessary and will carried out depending on 'Homing' setting (Refer to 'Power Up, Homing')



For safety function without human risk it is recommend using interlock function of the digital inputs, because no new homing is necessary after release of the interlock.  
Refer to 'Power connector IO' >> 'Digital Input'

## 4.6 Power Up

After power up or possibly after a reset of the valve homing is necessary to determine the plate position.

Refer to chapter «4.11.2 Homing»

## 4.7 Power Down, Power Failure Option

### 4.7.1 Power down behavior in case of power failure

Valve position before power failure:	Reaction of valve:
Closed (isolated)	Valve remains closed.
Valve open or in any intermediate position	The plate remains at the current position.



All parameters are stored in a power fail save memory.

### 4.7.2 Power Fail Option

Power Fail Option is circuit board that can store as much energy to close or open the valve in the event of a power failure.

Technical data

Charging Time	2 minutes max.
Durability	Up to 10 years @ 25°C ambient

These settings define what the valve is doing in case the power fails.



Valve must be equipped with the 'Power Failure Option'  
[61... -... C - ... or 61... -... H - ...]

For PFO retrofit and other options refer to chapter: «Spare parts».


Location: CPA/Navigation/Parameters: Power Fail Option

Parameter	Description
<b>Enable</b>	'True' enables the power fail reaction. 'False' there is no reaction on a power fail
<b>State</b>	<i>Battery is Charging</i> <i>Ready to Use</i> <i>Active</i> <i>Failure</i>
<b>Functionality</b>	<i>Open</i> <i>Close</i>
<b>Delay</b>	In seconds After this delay, the power failure reaction starts after the power failed. Helps to bridge a short power interruption.
<b>Battery Voltage</b>	Shows state of charge
<b>Power Fail Cycles</b>	Counts Power Failure

### 4.8 Service Port, CPA software


The 'Service port is designed for 'Local operation' with the software CPA - Control Performance Analyzer.

Note: Detailed help on the CPA is available in the help of the CPA itself.




#### 4.8.1 How to start

1. Connect service cable (USB A-B cable male-male) between PC and valve:



2. Double Click on 'CPA4.exe' to open the 'Control Performance Analyzer'




3. Click [Local] for Local operation to do configuration



When communication to service port is interrupted, the valve will change to remote operation. So when service cable will be disconnected or software will be shut down, the valve returns automatically to remote operation. This may result in an **immediate movement** of the valve depending on remote control.


#### 4.8.2 Update

It is easy to update to the latest version of the CPA which can be found on the VAT homepage:  
<https://www.vatvalve.com/downloads/software>



## 4.9 Display Information

There is a 4 digit display located on the controller. It displays configuration, status and position information. For details refer to following tables.



### 4.9.1 Power up

Description	Digit 1	Digit 2	Digit 3	Digit 4
<ul style="list-style-type: none"> <li>1<sup>st</sup> Power On: All dots are illuminated</li> </ul>	#	#	#	#
<ul style="list-style-type: none"> <li>2<sup>nd</sup> Valve series e.g. <b>67.0</b></li> </ul>		6	7	0
<ul style="list-style-type: none"> <li>3<sup>rd</sup> Firmware: generation.type e.g. <b>01.0C</b></li> </ul>	0	1	0	C
<ul style="list-style-type: none"> <li>4<sup>th</sup> Firmware: version.firmware e.g. <b>07.00</b></li> </ul>	0	7	0	0
<ul style="list-style-type: none"> <li>5<sup>th</sup> Controller configuration: e.g. <b>11.00</b></li> </ul>	<b>Controller</b> 1=H1 2=H2 3=H3 4=H4 5=H5 6=H6 7=H7	<b>Interface</b> 1=RS232/RS485 2=EtherCAT 3=DeviceNet 5=Logic 7=Profibus 8=CCLink 9=EtherNet	<b>Options</b> 00=none 01=SPS 02=PFO 03=Cluster 04=SPS + PFO 05=SPS + Cluster 06=PFO + Cluster 07=SPS + PFO & Cluster 08=PFO2 09=SPS + PFO2 0A=PFO2 + Cluster 0B=SPS + PFO2 + Cluster 0C=PFO3 0D=SPS + PFO3 0E=PFO3 + Cluster 0F=SPS + PFO3 + Cluster  SPS Sensor Power Supply PFO Power Failure Option	
'Ho' homing is running	H	o		



#### 4.9.2 Operation

Description / Mode	Digit 1	Digit 2	Digit 3	Digit 4
INIT (start up)	<b>I</b>	<b>n.</b>		
INIT (start up, leak tight)	<b>I</b>	<b>n.</b>		<b>C</b>
CLOSE	<b>C.</b>	<b>C, 0...100</b> valve position  C = closed, leak tight 0 = minimal conductance 100 = maximum opened		
OPEN	<b>O.</b>			
PRESSURE control	<b>P.</b>			
POSITION control	<b>A.</b>			
INTERLOCK Valve closed or open by digital input	<b>I.</b>			
HOLD (position frozen)	<b>H.</b>			
LEARN	<b>L.</b>			
SAFETY Refer to «Safety mode» for details.	<b>S.</b>			
POWER FAILURE	<b>F.</b>			

#### 4.9.3 Error

Description	Digit 1	Digit 2	Digit 3	Digit 4
Error number (xyz)	<b>E.</b>	<b>x</b>	<b>y</b>	<b>z</b>
alternately (if error code exist)				
Error code		<b>u</b>	<b>v</b>	<b>w</b>



For Error number / code. Refer to «Trouble shooting» for details

## 4.10 System Settings and States

### 4.10.1 Identification

#### 4.10.1.1 Serial Number

*Location: CPA/Parameters: System.Identification.Serial Number*

Parameter	Description
<b>Serial Number</b>	VAT specific number

#### 4.10.1.2 Configuration

*Location: CPA/Parameters: System.Identification.Configuration*

Parameter	Description
<b>Valve Series</b>	3-digit value representing the VAT valve series
<b>Valve Variant</b>	For some vale there exists different variants
<b>Nominal Diameter</b>	DN in mm. E.g DN250
<b>Drive Parameter ID</b>	ID of the last drive file loaded on the valve. Sets the parameters responsible for the movement characteristics of the valve
<b>Configuration Parameters ID</b>	ID of the last configuration file loaded on the valve. Configuration of Interface, Pressure Control, Pressure Sensor, ...

#### 4.10.1.3 Firmware

*Location: CPA/Parameters: System.Identification.Firmware*

Parameter	Description
<b>Valve Firmware ID</b>	VAT specific identification number
<b>Valve Firmware Version</b>	Faa.bb.cc.dd a = Platform, Controller Type b = Type <b>C</b> ustomer <b>B</b> asis <b>P</b> roduction <b>T</b> est c = Version d = Revision
<b>CPA Version</b>	VAT PC software version
<b>Interface Firmware Version</b>	Network controller firmware
<b>Motion Controller Firmware Version</b>	Motion controller firmware

#### 4.10.1.4 Hardware

*Location: CPA/Parameters: System.Identification.Hardware*

Parameter	Description
<b>Controller Type</b>	Identification of the use controller IC2H1, IC2H2, IC2H3 ...
<b>Interface Type</b>	RS232/RS485 EtherCAT DeviceNet Logic Profibus CCLink EtherNet
<b>Option Type</b>	none SPS PFO Cluster SPS & PFO SPS & Cluster PFO & Cluster SPS & PFO & Cluster SPS...Sensor Power Supply PFO...Power Failure Option

#### 4.10.2 Statistics

*Location: CPA/Parameters: System.Statistics*

Parameter	Description
<b>Start Up Counter</b>	Each start up is counted (power on and resets) Can be used to monitor whether the valve has restarted uninvited (power loss, watchdog, ...)
<b>Total Time Powered Up</b>	In seconds
<b>Time Since Power On</b>	In seconds

**4.10.3 Warning/Error**

*Location: CPA/Parameters: System.Warning/Error*

Parameter	Description			
<b>Warning Bitmap</b>	Bit	Hex	Description	
	0	1	No Learn Data	
	1	2	Isolation valve does not work	
	2	4	No Sensor Active	
	3	8	PFO Not Ready	
	4	16	Cluster Slave Offline	
	6	40	Fieldbus Data Not Valid	
	8	256	Compressed Air Not Falling when valve close	
	9	512	Compressed Air Too Low	
	10	1024	Compressed Air Too High	
	12	4096	Fan stall alarm	
	<b>Error Bitmap</b>	Bit	Hex	Description
		0	1	Homing Position Error
1		2	Homing Not Running	
2		4	Homing Error State	
3		8	Operation Position Error	
4		10	Operation Not Running	
5		20	Operation Error State	
12		1000	Other Component	
30		40000000	General	
31		80000000	Internal	
<b>Error Number</b>		Refer to Error Number in Troubleshooting		
<b>Error Code</b>	Refer to Error Code in Troubleshooting			

**4.10.4 Service**

**4.10.4.1 Restart, Error Recovery**

*Location: CPA/Parameters: System.Services*

Parameter	Description
<b>Restart Controller</b>	Emulates a power cycle of the valve
<b>Error Recovery</b>	Attempts to reset the Control Mode Error without restarting the valves

**4.10.4.2 Settings Handling**

*Location: CPA/Parameters: System.Services.Store/Restore Settings*

Parameter	Description
<b>Store User Parameters</b>	Emulates a power cycle of the valve
<b>Restore User Parameters</b>	Attempts to reset the Control Mode Error without restarting the valves
<b>Restore Factory Parameters</b>	Protective function against changing the settings. If TRUE, the settings can no longer be changed.

*Location: CPA/Parameters: System.Services.Configuration Lock*

Parameter	Description
<b>Configuration Lock Mode</b>	Protective function against changing the settings. If TRUE, the settings can no longer be changed.

## 4.11 Valve Settings and States

### 4.11.1 States

*Location: CPA/Navigation/Parameters: Valve*

Parameter	Description
<b>Actual Position</b>	Show position of the valve plate
<b>Position State</b>	Intermediate Closed Open
<b>Isolation State</b>	Not Isolated Isolated

### 4.11.2 Homing

After power up or possibly after a reset of the valve homing is necessary to determine the plate position.

*Location: CPA/Navigation/Parameters: Valve.Homing*

Parameter	Description
<b>Start Condition</b>	Homing start option defines when the valve performs the homing procedure. <i>Standard</i> Automatically if valve is not in sealed state, otherwise it is waiting for a move command. <i>Open Command</i> On an open command <i>Move Command</i> On any move command <i>At Startup</i> All the time <i>Homing Command</i> On homing command <i>Move Command Without Close</i> On any move command except close command if the valve is closed
<b>End Control Mode</b>	This control mode is set after a successful homing. <i>Position</i> <i>Close</i> <i>Open</i> <i>Pressure Control</i>
<b>End Position</b>	In case the <b>End Control Mode</b> is set to 2 (Position), this parameter defines which position is set after successful homing.

Followed description of the **standard setting**:

Valve position before power up:	Reaction of valve:
Closed (isolated)	Valve remains closed. Homing will be done when first movement command is received.
All other than closed (not isolated)	Valve do homing to initialize position. Display shows 'Ho' until homing is done Valve position after homing is closed

### 4.11.3 Cycle Counter

#### 4.11.3.1 Control Cycle

A control cycle is a complete movement of the valve, from closing to opening and back to closing, or in percentage of movement it is 200%. Each movement is added up until 200% of the movement is reached, and then the cycle counter is incremented by 1.

*Location: CPA/Parameters: Valve.Position Cycle Counter*

Parameter	Description
<b>Control Cycles</b>	The value is writable to be able to reset it
<b>Control Cycles Total</b>	Non-resettable value

#### 4.11.3.2 Isolation Cycle

Counts each compression of the O-ring during the closing process (Each transition of **Isolation State** from 'Not Isolated' to 'Isolated')

*Location: CPA/Parameters: Valve.Position Cycle Counter*

Parameter	Description
<b>Isolation Cycles</b>	The value is writable to be able to reset it
<b>Isolation Cycles Total</b>	Non-resettable value

### 4.11.4 Position Restriction

This allows the position of the valve to be limited in open direction. The limitation is effective in any control mode

If restriction is active:

- **Position State** remains in Intermediate
- Digital outputs Open becomes not active

*Location: CPA/Parameters: Valve.Position Restriction*

Parameter	Description
<b>Enable</b>	Enable the restriction
<b>Maximum Position</b>	High position limit
<b>Restriction Active</b>	Indicates that the position is currently restricted by the Position Restriction.

## 4.11.5 Position Adaption

### 4.11.5.1 Usage

#### Chamber Matching

Adjustment of the conductance curve of different valves to obtain the same position at the same process points in different systems.

#### Cluster Balance


Adjusting the Position of individual valves in a valve cluster can be used to compensate certain Side-effects, e.g. keeping suction rate of downstream pump on a defined level.

### 4.11.5.2 Parameters

Location: CPA/Parameters: Valve.Position Adaption

Parameter	Description
<b>Enable</b>	Enables the adaption
<b>Mode</b>	Mode of the adaption. Currently only <i>Offset</i> is available.
<b>Actual Position Mode</b>	Selection of the position which the valve indicates <i>Real</i> <i>Adapted</i>
<b>Offset</b>	Amount of displacement of the position
<b>Target Position In</b>	Value sent via Interface or CPA Is the same as <b>Position Control.Target Position</b>
<b>Target Position Used</b>	Internal used Target Position = Target Position In + Offset
<b>Actual Position Real</b>	Internal real position If setting <b>Actual Position</b> = <i>Real</i> the valve indicates this position
<b>Actual Position Adapted</b>	Actual Position Real – Offset If setting <b>Actual Position</b> = <i>Adapted</i> the valve indicates this position

Example: shows parameter window with the offset values and behind the main window with the position values




## 4.12 Interface DeviceNet

DeviceNet was originally developed by Allen-Bradley (now owned by Rockwell Automation). It is an application layer protocol on top of the CAN (Controller Area Network) technology, developed by Bosch. DeviceNet adapts the technology from the Common Industrial Protocol and takes advantage of CAN, making it low-cost and robust compared to the traditional RS-485 based protocols.

DeviceNet is standardized in the European standard EN 50325. Specification and maintenance of the DeviceNet standard are the responsibility of ODVA ([www.odva.org](http://www.odva.org)). DeviceNet, like ControlNet and EtherNet/IP, belongs to the family of CIP-based networks. CIP (Common Industrial Protocol) forms the common application layer of these three industrial networks. DeviceNet is an object-oriented bus system and operates according to the producer/consumer method. DeviceNet devices can be client (master) or server (slave) or both. Clients and servers can be producer, consumer or both.

In a DeviceNet network, up to 64 bus nodes can communicate with each other at baud rates of 125, 250 or 500 kBaud. In addition to the two signals for CAN-L and CAN-H data transmission, the DeviceNet cable also provides two lines for supplying the DeviceNet bus nodes with 24-volt operating voltage. The bus nodes can be bus-powered or externally powered. The maximum length of the DeviceNet cable depends on the selected cable type and baud rate. The installation is done in a bus topology - with or without branches - and terminating resistors at both ends. The terminating resistors have a value of 120 ohms.



The main area of application for DeviceNet is factory automation with components such as I/O modules, valves, encoders, drives and controllers (PLCs). Within the CIP network family, DeviceNet thus covers a large part of the applications in which small to medium data volumes are to be transmitted with short to medium cycle times (1 ms to 500 ms).



#### 4.12.1 Introduction

The following Object Modeling related terms are used when describing services and protocol:

- **Object** – An abstract representation of a particular component within a product.
- **Class** – A set of objects that all represent the same kind of system component. A class is a generalization of an object. All objects in a class are identical in form and behavior, but may contain different attribute values.
- **Instance** – A specific and real (physical) occurrence of an object. For example: New Zealand is an instance of the object class Country. The terms Object, Instance, and Object Instance all refer to a specific Instance.
- **Attribute** – A description of an externally visible characteristic or feature of an object. Typically, attributes provide status information or govern the operation of an Object. For example: the ASCII name of an object; and the repetition rate of a cyclic object.
- **Service** – A function supported by an object and/or object class (set, get, reset,...)

Object Model Terminology Example:

Class	Instance	Attribute	Attribute Values
Human	Mary	Gender	Female
		Age	31
	Jerry	Gender	Male
		Age	50

#### 4.12.2 EDS File

The Electronic Data Sheet (EDS) contains all communication parameters of the device as well as the available objects. The DeviceNet configuration tool reads the EDS files of the devices present in the network and calculates the configuration data from them, which are then loaded into the DeviceNet nodes.


ESI files can be downloaded from [www.vatvalve.com/downloads](http://www.vatvalve.com/downloads)

Select the 'Software & Updates' tab and enter 'EDS' in the search field. All available EDS files will be listed. If the appropriate EDS file is not available, please contact VAT: [www.vatvalve.com/contact](http://www.vatvalve.com/contact)

4.12.3 Messaging Format


4.12.3.1 Explicit Messaging Connections

Explicit Messaging Connections, (see figure below) provide generic, multi-purpose communication paths between two devices. An Explicit Message consists of a Connection ID and associated messaging protocol information. Explicit messaging connections utilize a direct request / response format which allow you to access any attribute data. Explicit




4.12.3.2 I/O Poll Messaging Connections

I/O poll messaging connections, (see figure below) utilize an assembly format to group and report data from multiple objects using a single communications command. These connections are typically used for quick reporting of information (run-time).



#### 4.12.4 Objects

Object Model



Nr	Object Class	# of Instances	Description
1	Identity	1	Identification of and general information about the device
2	Message Router	1	Distributes Explicit Request Messages to the appropriate handler object
3	Device Net	1	Provides the configuration and status of a DeviceNet port
4	Assembly	7 Input, 3 Output	Groups attributes of multiple objects into a single assembly
5	Connection	>4	Manage the characteristics of a communication connection
8	Discrete Input Point	2	Defines the interface to the open/close limit switches
48	S-Device Supervisor	1	Centralizes application object state definitions and related status information
49	S-Analog Sensor	2	Models the acquisition of a reading from a physical sensor in a device
51	S-Single Stage Controller	2	Models a closed-loop control system within a device
100	Pressure Controller		VAT specific attributes

#### 4.12.5 Identity Object (Class ID 1)

The Identity Object provides general information about the device

Attr.	Name	Data Type	Min	Max	Default	Access	NV	Unit	Description Semantic Of Value
1	Vendor ID	UINT16	404	404	404	GET	1		Identification of each vendor by number
2	Device Type	UINT16	0	0	0	GET	1		Indication of general type of product
3	Product Code	UINT16	0	DT	0	GET	1		Identification of a particular product of an in
4	Revision	STRUCT	0	DT	0	GET	1		Revision of the item the Identity Object is rep Byte 0 = Major Revision Byte 1 = Minor Revision
5	Status	UINT16	0	DT	0	GET	0		Summary status of device Bit 0 = Owned Bit 2 = Configured Bit 4-7 = Extended Device Status Bit 8 = Minor Recoverable Fault Bit 9 = Minor Unrecoverable Fault Bit 10 = Major Recoverable Fault Bit 11 = Major Unrecoverable Fault All other bits reserved
6	Serial Number	UINT32	0	DT		GET	1		Serial number of device in conjunction with V identifier
7	Product Name	STRING				GET	1		Human readable identification

#### 4.12.6 Device Net Object (Class ID 3)

Attr.	Name	Data Type	Min	Max	Default	Access	NV	Unit	Description Semantic Of Value
1	MAC ID	UINT8	0	63	63	SET	1		
2	Baud Rate	UINT8	0	2	0	SET	1		125kB, 250kB, 500kB

#### 4.12.7 Assembly Object (Class ID 4)

Groups attributes of multiple objects into a single assembly

Attr.	Name	Data Type	Min	Max	Default	Access	NV	Unit	Description Semantic Of Value
100	Poll Output Assembly	UINT8	7	8		SET	1		Assembly Instance used by the Poll connect 7,8,102
101	Poll Input Assembly	UINT8	3	101		SET	1		Assembly Instance used by the Poll connect 3,4,5,13,14,100,101
102	Bit Strobe Input	UINT8				SET	1		Not implemented
103	Change of state cycling input	UINT8	3	101		SET	1		3,4,5,13,14,100,101

**4.12.7.1 Assemblies**

Output

Instance	Composition	Class/Instance/Attribute		Int			Real		
		Source	Data Type	Start	Length	Total	Start	Length	Total
100	Exception Status	100/1/1	UINT8	0	1	5	0	1	9
	Pressure		Int/Real	1	2		1	4	
	Position	100/1/2	Int/Real	3	2		5	4	

**Input**

Number	Composition	Integer			Float		
		Start	Length	Total	Start	Length	Total
3 (default)	EXCEPTION STATUS	0	1		0	1	
	PRESSURE	1	2	5	1	4	9
	POSITION	3	2		5	4	
4	EXCEPTION STATUS	0	1		0	1	
	PRESSURE	1	2	5	1	4	9
	SETPOINT <sup>1)</sup>	3	2		5	4	
5	EXCEPTION STATUS	0	1		0	1	
	PRESSURE	1	2		1	4	
	SETPOINT <sup>1)</sup>	3	2	7	5	4	13
	POSITION	5	2		9	4	
13 Dh	EXCEPTION STATUS	0	1		0	1	
	EXCEPTION DETAIL ALARM	1	15	31	1	15	31
	EXCEPTION DETAIL WARNING	16	15		16	15	
14 Eh	EXCEPTION STATUS	0	1		0	1	
	PRESSURE	1	2		1	4	
	POSITION	3	2	6	5	4	10
	VALVE CLOSED / OPEN CHECK <sup>2)</sup>	5	1		9	1	
100 64h	EXCEPTION STATUS	0	1		0	1	
	PRESSURE	1	2		1	4	
	POSITION	3	2	7	5	4	11
	CONTROLLER MODE	5	1		9	1	
	ACCESS MODE	6	1		10	1	
101 65h	EXCEPTION STATUS	0	1		0	1	
	PRESSURE	1	2		1	4	
	POSITION	3	2	7	5	4	11
	VALVE CLOSED / OPEN CHECK <sup>2)</sup>	5	1		9	1	
	CONTROLLER MODE	6	1		10	1	

**Output**

Number	Composition <sup>2)</sup>	Integer			Float		
		Start	Length	Total	Start	Length	Total
7	SETPOINT <sup>1)</sup>	0	2	3	0	4	5
	SETPOINT TYPE	2	1		4	1	
8 (default)	CONTROL MODE	0	1		0	1	
	SETPOINT <sup>1)</sup>	1	2	4	1	4	6
	SETPOINT TYPE	3	1		5	1	
102 66h	CONTROL MODE	0	1		0	1	
	SETPOINT <sup>1)</sup>	1	2		1	4	
	SETPOINT TYPE	3	1	8	5	1	12
	LEARN <sup>3)</sup>	4	1		6	1	
	LEARN PRESSURE LIMIT	5	2		7	4	
ZERO <sup>3)</sup>	7	1		11	1		

1) PRESSURE SETPOINT or POSITION SETPOINT depending on related SETPOINT TYPE

2) 0 = Valve is neither closed nor open, 1 = Valve is CLOSED, 2 = Valve is OPEN

3) To activate ZERO or LEARN use 1 as data else 0.

Apply always correct procedures as described in «Zero Adjust» or «Learn (adaptive control algorithm)»

#### 4.12.8 Discrete Input Object (Class ID 8)

Defines the interface to the open/close limit switches

Attr.	Name	Data Type	Min	Max	Default	Access	NV	Unit	Description Semantic Of Value
3	Value	BOOL	0	1	-	GET	0		0 Open, 1 Closed
4	Status	BOOL	0	1					0 OK, 1 Alarm
100	Close Open Check	UINT8	0	2					0 Closed, 1 Opened, 2 Intermediate

Instance 1 Close  
Instance 2 Open

**4.12.9 S-Device Supervisor Object (Class ID 48)**

Centralizes application object state definitions and related status information

Command	Service Code		Class ID	Instance ID	Attribute ID	Service data length <small>(number of bytes)</small>	Service data field
	Description						
<b>DEVICE STATUS</b>	Get	14	48	1	11	1	X
	X: <ul style="list-style-type: none"> <li>1 self test</li> <li>2 idle</li> <li>3 self test exception</li> <li>4 executing</li> <li>5 abort</li> </ul> This attribute represents the current state of the device. <b>Note:</b> EXECUTING must be selected to enable for all executing commands. <b>Note:</b> A successfully established Poll-IO connection switches the DEVICE STATUS to executing.						
<b>EXECUTING (START)</b>	6	48	1	-	3	-	-
	This command changes the DEVICE STATUS to executing state. <b>Note:</b> If DEVICE STATUS is already in executing state a new EXECUTING results in an error return.						
<b>IDLE (STOP)</b>	7	48	1	3	-	-	-
	This command changes the DEVICE STATUS to idle state.						
<b>EXCEPTION STATUS</b>	Get	14	48	1	12	1	
	The exception status byte only indicates that alarms or warnings are present. For details see EXCEPTION DETAIL ALARM resp. EXCEPTION DETAIL WARNING.						
	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1
1	Manufacturer specific warning	reserved	reserved	reserved	Manufacturer specific alarm	reserved	reserved




Command	Service Code		Class ID	Instance ID	Attribute ID	Service data length (number of bytes)	Service data field			
	Description									
<b>EXCEPTION DETAIL ALARM</b>  <b>EXCEPTION DETAIL WARNING</b>	Get	14	48	1	13 Alarm 14 Warning	15	See below			
	Table with EXCEPTION DETAIL ALARM resp. EXCEPTION DETAIL WARNING bits.									
		Data Component	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
	0	PCV Common Exception Detail Size	0	0	0	0	0	0	1	0
	1	PCV Common Exception Detail Byte #0	0	0	0	0	0	0	0	0
	2	PCV Common Exception Detail Byte #1	0	0	0	0	0	0	0	0
	3	PCV Device Exception Detail Size	0	0	0	0	0	1	0	0
	4	PCV Device Exception Detail Byte #0	0	0	0	0	0	0	0	0
	5	PCV Device Exception Detail Byte #1	0	0	0	0	0	0	0	0
	6	PCV Device Exception Detail Byte #2	0	0	0	0	0	0	0	0
	7	PCV Device Exception Detail Byte #3	0	0	0	0	0	0	0	0
	8	Manufacturer Exception Detail Size	0	0	0	0	0	1	1	0
	9	Manufacturer Exception Detail Byte #0 <b>Warning</b>	Reserved	Reserved	<b>External isolation valve failure</b>	Reserved	<b>PFO not ready</b>	<b>Compressed air failure</b>	<b>Learn data set invalid</b>	Reserved
	10	Manufacturer Exception Detail Byte #1 <b>Warning</b>	Reserved	Reserved	Reserved	Reserved	Reserved	<b>ADC not responding</b>	Reserved	Reserved
	11	Manufacturer Exception Detail Byte #2 <b>Warning</b>	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	No sensor
12	Manufacturer Exception Detail Byte #3 <b>Warning</b>	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	<b>PFO off</b>	<b>Simulation active</b>	
13	Manufacturer Exception Detail Byte #4 <b>Alarm</b>	Reserved	Reserved	Reserved	Reserved	<b>E40</b>	<b>E22</b>	<b>E21</b>	<b>E20</b>	
14	Manufacturer Exception Detail Byte #5 <b>Alarm</b>	Reserved	Reserved	Reserved	Reserved	<b>Setpoint invalid (safe state)</b>	<b>IO data missing (safe state)</b>	<b>Setpoint type invalid (safe state)</b>	<b>Control mode invalid (safe state)</b>	

Command	Service Code	Class ID	Instance ID	Attribute ID	Service data length (number of bytes)	Service data field
	Description					
<b>UPLOAD LEARN DATA</b>	50	48	1	-	3,11	X,XY
	X: Index (3 byte, range <b>000</b> .. <b>103</b> , ASCII coded) Y: Data (8 byte) This command loads the learn data sets from the valve up to the host. There are a total number of 104 data sets which need to be uploaded separately. Example: Send : "000" → 48 48 48 Response: "00000754241" → 48 48 48 48 48 55 53 52 50 52 49					
<b>DOWNLOAD LEARN DATA</b>	51	48	1	-	11,3	XY,X
	X: Index (3 byte, range <b>000</b> .. <b>103</b> , ASCII coded) Y: Data (8 byte) This command loads the learn data sets from host down to the valve. There are a total number of 104 data sets which need to be downloaded separately. Example: Send: "00000754241" → 48 48 48 48 48 55 53 52 50 52 49 Response: "000" → 48 48 48					

#### 4.12.10 S-Analog Sensor Object (Class ID 49)

Models the acquisition of a reading from a physical sensor in a device

Command	Service Code	Class ID	Instance ID	Attribute ID	Service data length (number of bytes)	Service data field	
	Description						
<b>DATA TYPE</b>	Set	16	49	1	3	1	X
	Get	14					
	X: <b>195</b> signed integer <b>202</b> floating point This command defines the data type for all pressure and position values. Default value is 195.						
<b>PESSURE POSITON READING</b>	Get	14	49	1 Pressure 3 Position	6	2 integer 4 float	X
	X: Instance 1 pressure Nominal range pressure is <b>0</b> ... <b>10'000</b> but it may be scaled. Refer also to command GAIN and picture on the following page for details.  X: Instance 3 position Nominal range is <b>0</b> (closed) ... <b>10'000</b> (open). Refer also to command GAIN and picture on the following page for details.						

Command	Service Code		Class ID	Instance ID	Attribute ID	Service data length (number of bytes)	Service data field												
	Description																		
GAIN	Set	16	49	1 Pressure 3 Position	14	4 float	X												
	Get	14																	
	<p>X: Gain, max. value is <b>3.2767</b>, data type is floating point This command selects the gain for PRESSURE/POSITION and allows for scaling. Default value is 1.0</p> <p>Example:</p> <table border="1"> <thead> <tr> <th>Gain</th> <th>X (hex)</th> <th>Resulting range</th> </tr> </thead> <tbody> <tr> <td>0.1</td> <td>3D CC CC CC</td> <td>0 ... 1000</td> </tr> <tr> <td>1.0</td> <td>3F 80 00 00</td> <td>0 ... 10000</td> </tr> <tr> <td>3.2767</td> <td>40 51 B5 73</td> <td>0 ... 32767</td> </tr> </tbody> </table>							Gain	X (hex)	Resulting range	0.1	3D CC CC CC	0 ... 1000	1.0	3F 80 00 00	0 ... 10000	3.2767	40 51 B5 73	0 ... 32767
	Gain	X (hex)	Resulting range																
0.1	3D CC CC CC	0 ... 1000																	
1.0	3F 80 00 00	0 ... 10000																	
3.2767	40 51 B5 73	0 ... 32767																	
SENSOR MODE	Set	16	49	1	101	1	X												
	Get	14																	
	<p>X: 0 = no sensor 1 = sensor 1 2 = sensor 1 high, sensor 2 low, crossover fade 7 = sensor 1 high, sensor 2 low, crossover target pressure 9 = sensor 1 high, sensor 2 low, crossover switch point</p> <p>3 = sensor 2 4 = sensor 2 high, sensor 1 low, crossover fade 8 = sensor 2 high, sensor 1 low, crossover target pressure 10 = sensor 2 high, sensor 1 low, crossover switch point</p> <p> 2 sensor operation are possible with 2 sensor hardware [950...-...Q -....] only.</p> <p>For applications where the high range sensor is used for monitoring purpose only, select sensor operation modes 1 or 3 for pressure control with low range sensor and read high range sensor from SENSOR 1 READING resp. SENSOR 2 READING.</p>																		
ZERO CONTROL	Set	16	49	1	102	1	X												
	Get	14																	
<p>X: 0 Disable 1 Enable</p> <p>In case ZERO CONTROL is disabled ZERO ADJUST does not work.</p>																			
ZERO ADJUST	75		49	1	-	0	-												
	<p>This service initiates ZERO ADJUST.</p> <p><b>Note:</b> Refer to «Fehler! Verweisquelle konnte nicht gefunden werden.» for correct zero procedure.</p>																		

**Note:** Pressure Reading and Offset Values of Sensor 1 and Sensor 2 are in Pressure Controller Object (Class ID 100)

**4.12.11 S-Single Stage Controller Object (Class ID 51)**

Models a closed-loop control system within a device

Command	Service Code		Class ID	Instance ID	Attribute ID	Service data length (number of bytes)	Service data field
	Set	Get					
<b>SETPOINT TYPE</b> (Single Stage Controller Instance)	Set	16	51	0	8	1	X
	Get	14					
	X: <b>0</b> instance 1 - pressure control <b>1</b> Instance 2 - position control Defines the active instance of the single stage controller						
<b>CONTROL MODE</b>	Set	16	51	1 pressure 2 position	5	1	X
	Get	14					
	X: <b>0</b> control <b>1</b> close <b>2</b> open <b>3</b> hold (stops the valve at the current position) <b>4</b> safe state (valve will close)						
<b>CONTROL SETPOINT</b>	Set	16	51	1 pressure 2 position	6	2 integer 4 float	X
	Get	14					
	X:     Instance 1 pressure Target pressure, nominal pressure range is <b>0 ... 10'000</b> (sensor full scale) But it may be scaled, refer also to command GAIN for details.  X:     Instance 2 position Target position, nominal position range is <b>0 (closed) ... 10'000</b> (open) But it may be scaled, refer also to command GAIN for details.						
<b>VALVE SPEED</b>	Set	16	51	2	101	2 integer	X
	Get	14					
	X:     valve speed, <b>1 ... 1000</b> (1 = min. speed, 1000 = max. speed), This command selects/returns the actuating speed for the valve plate. Speed selection is effective for pressure control and position control. Open valve and close valve are always done with max. speed. <b>Note:</b> Refer to «Valve speed adjustment» for details.						
<b>ADAPTIVE CONTROL GAIN FACTOR</b>	Set	16	51	1	105	1	X
	Get	14					
	X: <b>0 = 0.10, 1 = 0.13, 2 = 0.18, 3 = 0.23, 4 = 0.32, 5 = 0.42, 6 = 0.56</b> <b>7 = 0.75, 8 = 1.00, 9 = 1.33, 10 = 1.78, 11 = 2.37, 12 = 3.16, 13 = 4.22</b> <b>14 = 5.62, 15 = 7.50, 16 = 0.0001, 17 = 0.0003, 18 = 0.001, 19 = 0.003,</b> <b>20 = 0.01, 21 = 0.02, 22 = 0.05</b> <b>Note:</b> Refer to «Gain factor adjustment» for details.						

Command	Service Code		Class ID	Instance ID	Attribute ID	Service data length (number of bytes)	Service data field										
	Description																
ADAPTIVE CONTROL SENSOR DELAY	Set	16	51	1	107	1	X										
	Get	14															
	X: <b>0</b> = 0, <b>1</b> = 0.02, <b>2</b> = 0.04, <b>3</b> = 0.06, <b>4</b> = 0.08, <b>5</b> = 0.10, <b>6</b> = 0.15 <b>7</b> = 0.20, <b>8</b> = 0.25, <b>9</b> = 0.30, <b>10</b> = 0.35, <b>11</b> = 0.4, <b>12</b> = 0.5, <b>13</b> = 0.6 <b>14</b> = 0.8, <b>15</b> = 1.0 <b>Note:</b> Refer to «Sensor delay adjustment» for details.																
PRESSURE CONTROL SETPOINT RAMP	Set	16	51	1	108	1	X										
	Get	14															
	X: <b>0</b> = 0, <b>1</b> = 0.5, <b>2</b> = 1.0, <b>3</b> = 1.5, <b>4</b> = 2.0, <b>5</b> = 2.5, <b>6</b> = 3.0 <b>7</b> = 3.5, <b>8</b> = 4.0, <b>9</b> = 4.5, <b>10</b> = 5.0, <b>11</b> = 5.5, <b>12</b> = 6.0, <b>13</b> = 6.5 <b>14</b> = 7.0, <b>15</b> = 7.5, <b>16</b> = 8.0, <b>17</b> = 8.5, <b>18</b> = 9.0, <b>19</b> = 9.5, <b>20</b> = 10.0 <b>Note:</b> Refer to «Setpoint ramp adjustment» for details.																
LEARN (calibration service)	99		51	1	0	-	-										
	This command starts LEARN. With CONTROL MODE commands open valve or close valve the routine may be interrupted. <b>Note:</b> Without LEARN the PID controller is not able to perform pressure control. <b>4.12.12 Refer to «Adaptive algorithm»</b>  This control algorithm may be used for downstream pressure control. Before using adaptive control algorithm, a special procedure called “learn” must be executed first (see chapter below).  <b>4.12.12.1 Control Parameter</b>  <i>Location: CPA/Navigation/Parameters: Pressure Control.Controller x.Control Settings</i> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><b>Gain Factor</b></td> <td>Main parameter to adapt the performance of the pre algorithm. A higher gain results in a faster response, undershoots of pressure. A lower gain results in slow over- / undershoot of pressure.</td> </tr> <tr> <td><b>Sensor Delay</b></td> <td>For compensation of delays during the pressure detection orifices for sensor attachment can cause delays in response which could impact badly the pressure control stability. By adjusting this parameter to the approximate delay time stability procedure is reduced. But control response time will be slowed down.</td> </tr> <tr> <td><b>Learn Data Selection</b></td> <td>There are up to 4 different learn data sets available. By selecting a data set the adaptive controller shall use for pressure control.</td> </tr> <tr> <td><b>Ramp</b></td> <td>A set point ramp can be used to avoid overshoots... See chapter «Pressure Ramp»</td> </tr> </tbody> </table>							Parameter	Description	<b>Gain Factor</b>	Main parameter to adapt the performance of the pre algorithm. A higher gain results in a faster response, undershoots of pressure. A lower gain results in slow over- / undershoot of pressure.	<b>Sensor Delay</b>	For compensation of delays during the pressure detection orifices for sensor attachment can cause delays in response which could impact badly the pressure control stability. By adjusting this parameter to the approximate delay time stability procedure is reduced. But control response time will be slowed down.	<b>Learn Data Selection</b>	There are up to 4 different learn data sets available. By selecting a data set the adaptive controller shall use for pressure control.	<b>Ramp</b>	A set point ramp can be used to avoid overshoots... See chapter «Pressure Ramp»
	Parameter	Description															
<b>Gain Factor</b>	Main parameter to adapt the performance of the pre algorithm. A higher gain results in a faster response, undershoots of pressure. A lower gain results in slow over- / undershoot of pressure.																
<b>Sensor Delay</b>	For compensation of delays during the pressure detection orifices for sensor attachment can cause delays in response which could impact badly the pressure control stability. By adjusting this parameter to the approximate delay time stability procedure is reduced. But control response time will be slowed down.																
<b>Learn Data Selection</b>	There are up to 4 different learn data sets available. By selecting a data set the adaptive controller shall use for pressure control.																
<b>Ramp</b>	A set point ramp can be used to avoid overshoots... See chapter «Pressure Ramp»																
Learn» for correct learn gas flow and procedure.																	
	Set	16	51	1	100	2 integer 4 float	X										
	Get	14															

Command	Service Code	Class ID	Instance ID	Attribute ID	Service data length <small>(number of bytes)</small>	Service data field									
<p align="center"><b>LEARN PRESSURE LIMIT</b> (calibration scale)</p>	<b>Description</b>														
	<p>X: learn pressure limit according to selected DATA TYPE, nominal pressure range is <b>0 ... 10'000</b> (sensor full scale) but it may be scaled, refer also to command GAIN for details.</p> <p>This command transfers/reads the pressure limit for LEARN.</p> <p><b>4.12.13 Note: Refer to «Adaptive algorithm</b></p> <p>This control algorithm may be used for downstream pressure control.</p> <p>Before using adaptive control algorithm, a special procedure called "learn" must be executed first (see chapter below).</p> <p><b>4.12.13.1 Control Parameter</b></p> <p><i>Location: CPA/Navigation/Parameters: Pressure Control.Controller x.Control Settings</i></p> <table border="1" data-bbox="590 806 1390 1265"> <thead> <tr> <th>Parameter</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td><b>Gain Factor</b></td> <td>Main parameter to adapt the performance of the pre algorithm. A higher gain results in a faster response, undershoots of pressure. A lower gain results in slow over- / undershoot of pressure.</td> </tr> <tr> <td><b>Sensor Delay</b></td> <td>For compensation of delays during the pressure detection orifices for sensor attachment can cause delays in response which could impact badly the pressure control stability. By increasing this parameter to the approximate delay time stability precision is reduced. But control response time will be slowed down.</td> </tr> <tr> <td><b>Learn Data Selection</b></td> <td>There are up to 4 different learn data sets available. By selecting a data set the adaptive controller shall use for pressure control.</td> </tr> <tr> <td><b>Ramp</b></td> <td>A set point ramp can be used to avoid overshoots... See chapter «Pressure Ramp»</td> </tr> </tbody> </table> <p>Learn» for correct learn pressure limit setting.</p>						Parameter	Description	<b>Gain Factor</b>	Main parameter to adapt the performance of the pre algorithm. A higher gain results in a faster response, undershoots of pressure. A lower gain results in slow over- / undershoot of pressure.	<b>Sensor Delay</b>	For compensation of delays during the pressure detection orifices for sensor attachment can cause delays in response which could impact badly the pressure control stability. By increasing this parameter to the approximate delay time stability precision is reduced. But control response time will be slowed down.	<b>Learn Data Selection</b>	There are up to 4 different learn data sets available. By selecting a data set the adaptive controller shall use for pressure control.	<b>Ramp</b>
Parameter	Description														
<b>Gain Factor</b>	Main parameter to adapt the performance of the pre algorithm. A higher gain results in a faster response, undershoots of pressure. A lower gain results in slow over- / undershoot of pressure.														
<b>Sensor Delay</b>	For compensation of delays during the pressure detection orifices for sensor attachment can cause delays in response which could impact badly the pressure control stability. By increasing this parameter to the approximate delay time stability precision is reduced. But control response time will be slowed down.														
<b>Learn Data Selection</b>	There are up to 4 different learn data sets available. By selecting a data set the adaptive controller shall use for pressure control.														
<b>Ramp</b>	A set point ramp can be used to avoid overshoots... See chapter «Pressure Ramp»														
	Get	14	51	1	106	2 X									

Command	Service Code	Class ID	Instance ID	Attribute ID	Service data length (number of bytes)	Service data field
Description						
<b>LEARN STATUS</b> (calibration state)	<p>This command returns the status of the LEARN procedure. The status is binary coded.</p> <p>X:      Bit      Explanation:</p> <p>(LSB) 0      LEARN running</p> <p>         1      LEARN data set not present</p> <p>         2      LEARN terminated by user</p> <p>         3      Pressure in position OPEN                  &gt; 50% sensor full scale (of high range sensor in case of a 2 sensor system)                  or                  &gt; LEARN PRESSURE LIMIT</p> <p>         4      pressure in position 0                  &lt; 10% sensor full scale (of low range sensor in case of a 2 sensor system)</p> <p>         5      Pressure falling during LEARN</p> <p>         6      Sensor not stable during LEARN</p> <p>         7..9      reserved</p> <p>         10      LEARN terminated by controller</p> <p>         11      Pressure in position OPEN negative</p> <p>(MSB) 12..15 reserved</p>					

**4.12.14 Pressure Controller Object (Class ID 100)**

VAT specific attributes

Command	Service Code		Class ID	Instance ID	Attribute ID	Service data length (number of bytes)	Service data field
	Description						
<b>CONTROLLER MODE</b>	Get	14	100	1	103	1	X
	This command returns the device status. X: <b>1</b> = synchronization, <b>2</b> = POSITION CONTROL, <b>3</b> = CLOSED <b>4</b> = OPEN, <b>5</b> = PRESSURE CONTROL, <b>6</b> = HOLD , <b>7</b> = LEARN <b>12</b> = power failure, <b>13</b> = safety mode <b>14</b> = fatal error (read EXCEPTION DETAIL ALARM for details)						
<b>ACCESS MODE</b>	Set	16	100	1	107	1	X
	Get	14					
<b>THROTTLE CYCLE COUNTER</b>	Get	14	100	1	101	4	X
	X:     Data type is unsigned long integer. A movement from max. throttle position to open back to max. throttle position counts as one cycle. Partial movements will be added up until equivalent movement is achieved.						
<b>ISOLATION CYCLE COUNTER</b>	Get	14	100	1	106	4	X
	X:     Data type is unsigned long integer. Each closing of the sealing ring counts as one cycle.						
<b>HOMING END CONTROL MODE</b>	Set	16	100	1	112	1	X
	Get	14					
<b>POWER FAIL FUNCTIONALITY</b>	Set	16	100	1	113	1	X
	Get	14					



Command	Service Code	Class ID	Instance ID	Attribute ID	Service data length (number of bytes)	Service data field
	Description					
SENSOR 1 READING	Get	14	100	1	108	2 integer 4 float
	Nominal range is <b>0 ... 10'000</b> but it may be scaled. Refer also to command GAIN and picture on the following page for details.					
SENSOR 2 READING	Get	14	100	1	109	2 integer 4 float
	Nominal range is <b>0 ... 10'000</b> but it may be scaled. Refer also to command GAIN and picture on the following page for details.					
SENSOR 1 OFFSET	Get	14	100	1	110	2 integer 4 float
	This command returns the offset voltage adjusted by ZERO. Value range is <b>-1400 ... +1400</b> (-1.40V ... +1.40V).					
SENSOR 2 OFFSET	Get	14	100	1	111	2 integer 4 float
	This command returns the offset voltage adjusted by ZERO Value range is <b>-1400 ... +1400</b> (-1.40V ... +1.40V).					




## 4.13 Pressure Sensor

### 4.13.1 Mechanical connection requirements

Fast and accurate pressure control requires a fast sensor response. Sensor response time:  $< 50\text{ms}$ . The sensor is usually connected to the chamber by a pipe. The line must be short enough and the conductance must not be reduced by a too small line diameter or a low conductance shut-off valve. To maintain that the response time is not degraded by this connection it needs to meet the following requirements:

- Inner diameter of connection pipe:  $\geq 10\text{ mm}$
- Total length  $L1 + L2$ :  $\leq 300\text{ mm}$

The total conductance value must include all valves and limiting orifices that may also be present. Make also sure that there is no obstruction in front of sensor connection port inside the chamber. The sensor should also be mounted free of mechanical shock and vibration. Dynamic stray magnetic fields may introduce noise to sensor output and should be avoided or shielded.



### 4.13.2 Configuration

The CPA window shows a good overview of the sensor settings:

- The valve supports 2 sensors.
- Zero Adjust is for offset compensation of linear sensors
- Crossover is automatic switch over between 2 linear sensors

The screenshot shows the VAT Pressure Sensor configuration interface. It features a top navigation bar with 'Local', 'Remote', and 'Help' tabs. The main area is split into two columns for 'sensor 1' and 'sensor 2'. Each sensor configuration includes checkboxes for 'Available' and 'Enable', dropdown menus for 'Input Source' and 'Scale', and a 'range' section with 'Data Unit' and 'Upper/Lower Limit Data Value' fields. Below these are 'zero adjust' and 'filter' sections with 'Enable' checkboxes and numerical input fields. At the bottom, a 'zero adjust' section allows for 'Sensor Selection' and 'Target Pressure' setting, with an 'Execute Zero Adjust' button. A 'crossover' section includes 'Crossover Mode' and 'Threshold High/Low' settings. A note on the right side provides instructions for performing a zero adjust: 'Prior to executing a zero adjust: - Open Valve - Ensure no gas-flow in system'.

*Location: CPA/Navigation/Parameters: Pressure Sensor.Sensor 1, Pressure Sensor.Sensor 2*

Parameter	Description
<b>Available</b>	Set to 'True' if a sensor is connected
<b>Enable</b>	Set to 'True' if the sensor signal is used for pressure control
<b>Input Source</b>	<p><b>'Analog'</b> Sensor has an analog voltage interface and is direct connected to the valve.</p> <p><b>'Digital'</b> Sensor has an EtherCAT interface and is connected to the EtherCAT bus</p> <p><b>'Simulation'</b> Testing the valve and pressure control without being connected to the system</p>
<b>Range.Scale</b>	<p>Select type of the sensor signal</p> <p><b>'Linear'</b></p> <p><b>'Logarithmic'</b></p> <p>Most gauges are linear type gauges.</p>
<b>Range.Data Unit</b>	<p>Set the pressure data unit of the gauge:</p> <p><b>Pa, kPa, bar, mbar, Torr, mTorr, psia, psig</b></p>
<b>Range.Upper Limit Data Value</b> <b>Range.Lower Limit Data Value</b>	<p>Set the upper limit and lower limit of the gauge in the unit of "Range.Data Unit"</p> <p>Example for a 250mTorr linear sensor:</p> <p>Upper Limit = 250.0</p> <p>Lower Limit = 0.0</p>
<b>Range.Upper Limit Voltage Value</b> <b>Range.Lower Limit Voltage Value</b>	<p>These parameters are only used for gauges with analog voltage interface.</p> <p>The values corresponds to Range.Upper Limit Data Value and Range Lower Limit Data Value</p> <p>Example:</p> <p>Upper Limit: 10.0V → 250mTorr Range Upper Limit Data Value</p> <p>Lower Limit: 0.0V → 0.0mTorr Range Lower Limit Data Value</p>
<b>Filter.Enable</b>	'True' enables the filter
<b>Filter.Type</b>	<p>Set the filter type, which should be applied to the related Sensor Input:</p> <p><b>Low-pass, Low-pass Simple, Median, Moving Average, Line Frequency Suppression, FIR custom</b></p>
<b>Filter.Time</b>	<p>Set filter time in the range of 0.0 to 1.0 second.</p> <p>Note: Filter delays the sensor signals which is detrimental for pressure control</p>
<b>Value</b>	The actual Pressure value of the regarding Sensor

### 4.13.3 Crossover (2 sensor operation mode)

If two sensors are connected to the controller uses both for pressure control and pressure feedback. The controller selects each sensor or blends both sensor signals to the “**Actual Pressure**” used for control and feedback. Three different modes are selectable.

*Location: CPA/Navigation/Parameters: Pressure Sensor.Crossover*

Parameter	Description
<b>Crossover Mode</b>	Crossover between 2 sensors (see below)
<b>Threshold High [SFS low sensor]</b>	Defines the crossover area (see below)
<b>Threshold Low [SFS low sensor]</b>	The value is related to sensor full scale of low sensor (0.1 means 10% of sensor full scale of low sensor)
<b>Delay</b>	Switch over delay in Crossover Mode ‘Hard Switch’

**Crossover Mode Soft Switch**

Between the *Threshold Low* and *Threshold High* the controller blends both pressure signals to the actual pressure.

**When to use**  
This is the standard mode. Both pressure signals need to match in the crossover range otherwise crossover effect result (nonlinearity). Sensor full scale ratio low range to high range sensor must not exceed 1:100

---

**Crossover Mode Hard Switch**

Switching between sensors according to the hysteresis threshold levels and an optional delay.

**When to use**  
Preferred setting if the sensor signals do not fit together in the crossover area (for example if sensor ratio is high).

---

**Crossover Mode Target Pressure**

If Target Pressure is below low range sensor full scale low sensor is used; otherwise high range sensor.

**When to use**  
As there is no switchover during pressure control while using this setting, undesired effects like nonlinearity or continuous switching between sensors don't occur.

**Note**  
While in position control mode, 'Soft Switch' mode is used

#### 4.13.4 Zero Adjust

Zero Adjust allows for the compensation of the sensor offset voltage.

**Note:** A maximum offset voltage of +/- 1.4 V can be compensated.

*Location: CPA/Navigation/Parameters: Pressure Sensor.Zero Adjust*

Parameter	Description
<b>Zero Adjust.Sensor Selection</b>	Select the sensor for the zero adjust: <ul style="list-style-type: none"> <li>• Sensor 1 + 2</li> <li>• Sensor 1</li> <li>• Sensor 2</li> </ul>
<b>Zero Adjust.Target Pressure</b>	Normally this parameter is set to 0 in case the process chamber is fully evacuated (pressure <=1‰ of sensor full scale). If not you can align the sensor value to a known pressure (displayed on another readout in the system). In this case set <b>Target Pressure</b> to the known pressure. Note: Target Pressure is in the unit of pressure, see chapter «Scaling of Pressure and Position Values»
<b>Zero Adjust.Execute</b>	1: Start the zero adjust 2: Clear offset value After executing value return to 0
<b>Sensor 1.Enable</b> <b>Sensor 2.Enable</b>	0: It is not possible to execute a zero adjust. A present offset value is ignored 1: It is possible to execute a zero adjust. A present offset value is respected.
<b>Sensor 1.Offset Value [SFS]</b>	Value which is deducted from the measured sensor value.
<b>Sensor 2.Offset Value [SFS]</b>	The value is related to sensor full scale (0.1 means 10% of sensor full scale)

#### Performing a zero adjust:

1. Turn the gas flow off
2. Fully open the valve
3. Wait until the sensor signal is not shifting anymore. Refer to manual of sensor manufacturer for warm up time.
4. Wait until process chamber is evacuated.



Do not perform Zero Adjust, if the base pressure of your vacuum system is higher than 1‰ of sensor full scale. We recommend disabling Zero Adjust function or using of Zero Adjust.Target Pressure other than 0.0 in this case. Otherwise incorrect pressure reading is the result.

5. Perform zero with setting of Zero Adjust.Execute to 1
6. Check parameter Actual Pressure if the pressure is shifted as expected

### 4.13.5 Logarithmic Pressure

To control wide pressure ranges, it is advantageous to control with a logarithmic signal. Note: Only the PI and the Softpump controller can control with a logarithmic signal. Adaptive controller needs a linear signal.

*Location: CPA/Parameters: Pressure Sensor.General Settings.Logarithmic Pressure*

Parameter	Description
<b>Upper Limit Value</b>	Highest Value of the logarithmic value. Corresponds to the sensor full scale defined in the sensor setup.
<b>Percent Per Decade</b>	Defines the logarithmic scale
<b>Lowest Pressure</b>	Defines the lowest pressure that is converted to a logarithmic value. Corresponds to the smallest valid signal.
<b>Pressure On Interface</b>	Defines which signal scale is used on the interface. Linear Logarithmic
<b>Use Logarithmic Sensor</b>	Set to True to use direct the signal of a logarithmic sensor. <b>Percent Per Decade</b> is then not used. This parameter becomes active only if <b>Pressure Sensor.Sensor X.Range.Scale</b> is set to <b>Logarithmic</b>
<b>Actual Logarithmic Values</b>	Shows the logarithmic value. Full Scale is <b>Upper Limit Value</b>

**EXAMPLE:**

Sensor 1 linear 1000Torr, Sensor 2 linear 10Torr

With these sensors the measuring range is: 0.001Torr ... 1000Torr, so we cover 6 decades

<b>Percent Per Decade</b>	15 With 15% we cover 6.6 decades (100/15 = 6.6)														
<b>Lowest Pressure</b>	0.001Torr (~1mV of Low Sensor)														
<b>Upper Limit Value</b>	Shows 1000 (because SFS is 1000)														
<b>Actual Logarithmic Value</b>	Torr														
Example Values	<table border="0"> <tr><td>1000</td><td>1000</td></tr> <tr><td>850</td><td>100</td></tr> <tr><td>700</td><td>10</td></tr> <tr><td>550</td><td>1</td></tr> <tr><td>400</td><td>0.1</td></tr> <tr><td>250</td><td>0.01</td></tr> <tr><td>100</td><td>0.001</td></tr> </table>	1000	1000	850	100	700	10	550	1	400	0.1	250	0.01	100	0.001
1000	1000														
850	100														
700	10														
550	1														
400	0.1														
250	0.01														
100	0.001														
<b>Pressure On Interface</b>	Linear We want the logarithmic signal only on the pressure controller but not on the interface.														
<b>Use Logarithmic Sensor</b>	False Since the sensor signal is linear, there is no possibility to use a logarithmic signal from the sensor.														

Application: Soft Pump

Use of **Actual Logarithmic Value** in the pressure controller: Set **Pressure Control.Controller X.Control Settings.Pressure Scaler** to **Logarithmic**.

**Note:** Ramp value use logarithmic signal too, so **Ramp.Slope** is related to logarithmic scale.

For above example: **Slope [Torr]** = 15 means 15 of 1000 per Second what is 1.5% what corresponds to 0.15 Decade per Second.




## 4.14 Power Connector Digital IO



Do not connect other pins than indicated in the schematics!  
Use only screws with 4-40UNC thread for fastening the DA-15 connector!

### 4.14.1 Digital Input

#### 4.14.1.1 Connection



Pin	Default Function
12	<b>INPUT 1</b> Interlock Open
13	<b>INPUT 2</b> Interlock Close
14	<b>COMMON</b>

#### 4.14.1.2 Configuration

Location: CPA/Navigation/Parameters: Power Connector IO.Digital Input


Parameter	Description													
<b>Enable</b>	<b>1</b> enables the input													
<b>State</b>	<b>0</b> Not active <b>1</b> Active													
<b>Functionality</b>	<b>0</b> Interlock Open <b>1</b> Interlock Close <b>2</b> Hold													
<b>Inverted</b>	<table border="1"> <thead> <tr> <th>Input</th> <th>State</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td rowspan="2"><b>0</b> Not Inverted</td> <td>Off</td> <td>0 Off</td> </tr> <tr> <td>On</td> <td>1 On</td> </tr> <tr> <td rowspan="2"><b>1</b> Inverted</td> <td>Off</td> <td>1 Off</td> </tr> <tr> <td>On</td> <td>0 On</td> </tr> </tbody> </table>	Input	State	Function	<b>0</b> Not Inverted	Off	0 Off	On	1 On	<b>1</b> Inverted	Off	1 Off	On	0 On
Input	State	Function												
<b>0</b> Not Inverted	Off	0 Off												
	On	1 On												
<b>1</b> Inverted	Off	1 Off												
	On	0 On												



The INTERLOCK function has **priority** over the remote interface (HOLD does not)  
INTERLOCK CLOSE has **priority** over INTERLOCK OPEN

### 4.14.2 Digital Output

#### 4.14.2.1 Connection





Pin	Default Function
5	<b>OUTPUT 1</b> Open
6	<b>OUTPUT 2</b> Closed
7	<b>COMMON</b>

#### 4.14.2.2 Parameter, Configuration

Location: CPA/Navigation/Parameters: Power Connector IO.Digital Output

Parameter	Description																		
<b>Enable</b>	<b>1</b> enables the output																		
<b>State</b>	<b>0</b> Not active <b>1</b> Active																		
<b>Functionality</b>	<b>0</b> OPEN valve is fully open <b>1</b> CLOSE valve is fully closed (isolated if valve has an isolation function) <b>2</b> HOLD valve is in hold state																		
<b>Inverted</b>	<table border="1"> <thead> <tr> <th></th> <th>Function</th> <th>State</th> <th>Output</th> </tr> </thead> <tbody> <tr> <td rowspan="2"><b>0</b> Not Inverted</td> <td>inactive</td> <td>0</td> <td>Off</td> </tr> <tr> <td>active</td> <td>1</td> <td>On</td> </tr> <tr> <td rowspan="2"><b>1</b> Inverted</td> <td>inactive</td> <td>1</td> <td>On</td> </tr> <tr> <td>active</td> <td>0</td> <td>Off</td> </tr> </tbody> </table>		Function	State	Output	<b>0</b> Not Inverted	inactive	0	Off	active	1	On	<b>1</b> Inverted	inactive	1	On	active	0	Off
	Function	State	Output																
<b>0</b> Not Inverted	inactive	0	Off																
	active	1	On																
<b>1</b> Inverted	inactive	1	On																
	active	0	Off																

## 5 Operation

	<p style="text-align: center;"><b>⚠ WARNING</b></p> <p><b>Unqualified personnel</b> Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.</p>
	<p style="text-align: center;"><b>⚠ WARNING</b></p> <p><b>Valve opening</b> Risk of serious injury. Human body parts must be kept out of the valve opening and away from moving parts. Do not connect the controller to power before the valve is installed complete into the system.</p>

## 5.1 Access Mode

### 5.1.1 Overview

Defines whether the interface or the CPA via the service port has the rights to control the valve  
 Location: CPA/Parameters System

Access Mode	Control Permission	Comment
Local	CPA	
Remote	INTERFACE Master	CPA can switch to Local
Locked	INTERFACE Master	CPA can't switch to Local



Power On state is 'Remote'

### 5.1.2 Remote and Locked operation

This product is equipped with an interface to allow for remote operation.  
 See section «Interface» for details.


'Control Performance Analyzer' software may be used for monitoring during remote control.



In case 'Control Performance Analyzer' is used, make sure 'Remote' button is pushed to enable for remote operation.

### 5.1.3 Local operation


Local operation means that the valve is operated via the service port using a computer.  
 You can use our software 'Control Performance Analyzer' for Local operation, which is integrated in the controller. The software is beneficial especially for setup, testing and maintenance.




When communication to service port is interrupted the valve will change to remote operation. So when service cable will be disconnected or software will be shut down, the valve returns automatically to remote operation. This may result in an **immediate movement** of the valve depending on remote control.

## 5.2 Control Mode

The **Control Mode** represents the state machine of the valve. Writing to **Control Mode** requests a change in the state while reading **Control Mode** returns the actual state of the state machine.




<b>Init</b>	<b>State after power up. Remains if Homing is not started or no Exception occurs</b>
<b>Homing</b>	The valve performs the homing procedure to initialize the position. Refer to chapter Homing
<b>Position</b>	The valve moves to the desired <b>Target Position</b> .
<b>Close</b>	The valve closes.
<b>Open</b>	The valve opens.
<b>Pressure Control</b>	The valve controls to the desired <b>Target Pressure</b> . Refer to chapter Pressure Control
<b>Hold</b>	The valve remains in the actual position. Usage during Pressure Control: Reduce valve reaction during plasma ignition. Stopping the valve movement to evaluate the stability of the sensor, flow meter, ... Note: Change from <b>Control Mode Close</b> to <b>Hold</b> is not possible
<b>Learn</b>	The valve performs the system learn. Necessary for Adaptive Pressure Control. Refer to chapter Pressure Control/Adaptive Algorithm/Learn
<b>Interlock Open</b>	The valve opens and locks due to the actuation of a digital input. Release behavior: <b>Control Mode</b> changes to <i>Open</i> or to <i>Init</i> if no Homing was performed yet. Refer to Chapter Power IO
<b>Interlock Close</b>	The valve closes and locks due to the actuation of a digital input. Release behavior: <b>Control Mode</b> changes to <i>Close</i> or to <i>Init</i> if no Homing was performed yet. Refer to Chapter Power IO
<b>Power Failure</b>	Power loss occurred. The valve opens or closes (Only with optional Power Failure Option) Closing or opening behavior depends on set <b>Power Failure.Functionality</b> Refer to chapter Power Failure
<b>Safety</b>	The motor of the valve is powerless due to a digital input. Release behavior: <b>Control Mode</b> changes to <i>Init</i> Refer to chapter xxx
<b>Error</b>	The valve is in an error state, no movement possible. Recovery via <b>Services.Error Recovery</b> or <b>Services.Restart Controller</b> . Refer to chapter Trouble Shooting.



5.2.1 View

CPA



First digit on display




- I Init
- H Homing
- C Close
- O Open
- P Pressure Control
- A Position
- I Interlock Open or Close
- H Hold
- L Learn
- S Safety Mode
- F Power Failure
- E Error

## 5.3 Pressure Control


### 5.3.1 Controller units

The valve has four identical pressure controller units. **Controller Selector** defines which unit is used for the pressure control.



Most applications do not need more than one controller unit. But if the result of the pressure control does not meet the expectations, different controller units can be an option for optimization: With the four controller units it is possible to use a certain controller unit for a specific pressure set point. This controller unit can be parametrized optimally for this specific set point. With the **Automated Controller Selector** (see below) it is possible to change Controller depending on pressure ranges or on up- and down control.

The CPA window 'Pressure Control' shows an good overview of the control units and their features:



## 5.3.2 Control algorithm

### 5.3.2.1 Overview

**Adaptive** This is the most dynamic control algorithm. Before using adaptive control algorithm, a special procedure called “learn” must be executed first (see chapter below). The valve will observe the behavior of the vacuum system by moving the valve to different positions. During the learn procedure the valve performs an internal parameter estimation correspondent to the vacuum system.

Note: Adaptive control algorithm requires a **linear** sensor signal. If a logarithmic sensor is used the signal has to be linearized or PI algorithm has to be used.

**PI** This is a solid algorithm for pressure control. The performance will be behind the adaptive control algorithm. But if the condition varies a lot, it's possible that the adaptive control algorithm does not work properly so the PI algorithm provides the best result.

**Soft Pump/Vent** Is a modified PI control algorithm to pump down from atmospheric pressure or vent to atmospheric pressure. This control algorithm has been optimized to starts very carefully when opening the valve.



5.3.2.2 Choose correct control algorithm

System Configuration	Constant gas flow available		Constant gas flow not available
	Tv* <= 500 sec	Tv* > 500 sec	
<p><b>Downstream</b></p>	<b>Adaptive</b>		<b>PI</b>
<p><b>Upstream</b></p>			<b>PI</b>
<b>Soft Pump</b>	<b>Soft Pump</b>		

\* Use the formula below to define the applicable pressure control algorithm.

$$T_v = \frac{p_{SFS} \cdot CV}{q_L}$$

- q<sub>L</sub>** gasflow for learn [mbar/s]
- p<sub>SFS</sub>** sensor full scale pressure [mbar]
- T<sub>v</sub>\*** Vacuum time constant [sec]
- CV** Chamber Volume [l]

### 5.3.3 Adaptive algorithm

This control algorithm may be used for downstream pressure control.

Before using adaptive control algorithm, a special procedure called “learn” must be executed first (see chapter below).

#### 5.3.3.1 Control Parameter

*Location: CPA/Navigation/Parameters: Pressure Control.Controller x.Control Settings*

Parameter	Description
<b>Gain Factor</b>	Main parameter to adapt the performance of the pressure control algorithm. A higher gain results in a faster response, higher over- / undershoots of pressure. A lower gain results in slower response, lower over- / undershoot of pressure.
<b>Sensor Delay</b>	For compensation of delays during the pressure detection. Pipes and orifices for sensor attachment can cause delays in response time and could impact badly the pressure control stability. By adapting this parameter to the approximate delay time stability problems can be reduced. But control response time will be slowed down by this measure.
<b>Learn Data Selection</b>	There are up to 4 different learn data sets available. Select which Learn data set the adaptive controller shall use for pressure control.
<b>Ramp</b>	A set poin ramp can be use to avoid over shoots... See chapter «Pressure Ramp»


5.3.3.2 Learn

LEARN adapts the PID controller of the valve to the vacuum system and its operating conditions. LEARN must be executed only once during system setup. The LEARN routine determines the characteristic of the vacuum system. Based on this, the PID controller is able to run fast and accurate pressure control cycles.

This characteristic depends on various parameters such as chamber volume, conductance and flow regime. Therefore it must be performed with a specific gas flow according to instruction below. The result of LEARN is a pressure versus valve position data table. This table is used to adapt the PID parameters. The data table is stored in the device memory which is power fail save. The data table can be up-/downloaded via 'Control Performance Analyzer' software or remote interface. Due to encoding the data may not be interpreted directly.

By an OPEN VALVE, CLOSE VALVE, POSITION CONTROL or PRESSURE CONTROL command the routine will be interrupted.

Recorded Standard Learn



Resulting Learn Data



**Parameters Executing**

*Location: CPA/Navigation/Parameters: Pressure Control.Adaptive Learn*

Parameter	Description
<b>Start Learn</b>	Starts the learn
<b>Type</b>	<p>Standard A positioning sequence is executed and various measured values are recorded in the process.</p> <p>Short Opens the valve and measures the pumping speed. Information about flow and volume is required.</p> <p>Calculated Calculated the learn data with the pumping speed information.</p> <p>Short or Calculated can be used when there is no way to set a constant gas flow.</p>
<b>Bank Selection</b>	Select one of four learn bank to place the result of the learn procedure. Note: Be sure pressure controller select this learn bank!
<b>Pressure Limit [SFS]</b>	Limit pressure to which pressure the learn shall be executed. The value is related to the sensor full scale of high sensor. 1.0 means the whole pressure range of the sensors
<b>Pressure Limit</b>	Same value as above but in Pressure Unit
<b>Open Speed</b>	Define the speed for opening the valve during the learn procedure. May be necessary to prevent a pump from crashing. 1.0 means full speed
<b>Status</b>	State of the current learn <b>0:</b> Not Started <b>1:</b> In Progress <b>2:</b> Completed Successfully <b>3:</b> Aborted <b>4:</b> Failed
<b>Warning Info</b>	Warning of current learn procedure: <b>Bit 0:</b> Learn is running <b>Bit 1:</b> Checksum error (learn data corrupt) <b>Bit 2:</b> Learn procedure terminated by user <b>Bit 3:</b> Pressure at position open > 50% of pressure limit <b>Bit 4:</b> Pressure at minimal conductance position < 10 % of pressure limit <b>Bit 5:</b> Pressure falls while move valve in direction of close <b>Bit 6:</b> Pressure at open position does not match pressure of previous open <b>Bit 7:</b> Learn procedure terminated by program <b>Bit 8:</b> Pressure <= 0 at open position (no gas flow set?)

Sort Learn Parameter

Parameter	Description
<b>Chamber Volume</b>	Volume above the valve plate in Liter
<b>Gas Flow</b>	Gas flow during the short learn, must be constant during the short learn
<b>Gas Flow Unit</b>	Gas flow unit for above Gas Flow
<b>Pumping Speed</b>	Resulting pumping speed

Calculated Learn Parameter

Parameter	Description
<b>Pumping Speed</b>	Set pumping speed to calculate the learn data

## Parameters Learn Bank

*Location: CPA/Navigation/Parameters: Pressure Control.Adaptive Learn.Learn Bank x*

Parameter	Description	
<b>Status</b>	Not Used	Empty learn bank
	Available	Data available. Evaluation possible with the pressure position curve in the CPA/Navigation/Adaptive Learn Data
	Available with warnings	The data may still be suitable for pressure control. Evaluation possible with the pressure position curve in the CPA/Navigation/Adaptive Learn Datas
<b>Data</b>	Captured data in a non-readable format	
<b>Warning Info</b>	Displays warnings that occurred while learning for this learning bank. Show Warning Info above	
<b>Type</b>	Standard Short Calculated ..See description above	
<b>Delete Learn Bank Data</b>	Deletes the data of the learn bank	

**Execute a learn procedure**

1. Set specific gas flow according to calculation below or the calculation in the CPA → **'Adaptive Learn'** window:  
  
Learn does not need to be performed with the process gas. Instead N<sub>2</sub> or Ar may be used.
2. Set parameter **Bank Selection**, if only one learn is used take Bank 1. Be sure that the pressure controller also selects this learn bank!
3. Reduce **Open Speed** if it is critical for the chamber if the pressure drops rapidly when the valve is opened.
4. Set a **Pressure Limit [SFS]** limit if sensor full scale cannot or should not be reached.
5. Set parameter **Controller Mode** to **LEARN**.
6. Wait until the **Controller Mode** leaves the **LEARN** state → Learn is finished
7. Check if the learn was successful by checking if **Status** shows value 2 (=Completed Successfully). In best case **Warning Info** shows no warning.



- Sensor signal must not shift during LEARN. Wait until sensor signal is stable before LEARN is performed. Learn may take several minutes.
- Do not interrupt the routine as a single full run is required to ensure fast and accurate pressure control.
- The PID controller covers 5% to 5000% of the gas flow which was used for learn.

CPA window **'Adaptive Learn'**

Local Remote Help

valve type

Valve Series Simulation

Valve Variant Aluminium

Nominal Diameter DN80

Min Conductance [l/s] 0.8 edit

learn limits

Pressure Limit [mTorr] 100

Open Speed 1

Bank Selection Bank 1

working point table

Gas Flow Unit sccm

Pressure [mTorr]	Gas Flow [sccm]	Conductance [l/s]
100	250	31.67
80	80	12.67

learn process sequence

Recommended Gas Flow [sccm] 90.000

Start Learn Not Started

learn data

Delete All Learn Bank Data Adaptive Learn Data

### Gasflow calculation for Learn



Do not apply a different gasflow for learn than determined below. Otherwise pressure control performance may be insufficient. Required pressure / flow regime must be known to calculate the most suitable learn gas flow for a specific application.

**Note:** The subsequent calculation can be conveniently performed in the CPA/Navigation/Adaptive Learn > Gas Flow Calculation > Calculate

- At first it is necessary to find out about the required control range respectively its conductance values. Each working point (pressure / flow) must be calculated with one following formulas. Choose the applicable formula depending on units you are familiar with.

$$C_{WP} = \frac{1000 \cdot q_{WP}}{p_{WP}}$$

$C_{WP}$  required conductance of working point [l/s]  
 $q_{WP}$  **gasflow** of working point [**Pa m<sup>3</sup>/s**]  
 $p_{WP}$  **pressure** of working point [**Pa**]

$$C_{WP} = \frac{q_{WP}}{p_{WP}}$$

$C_{WP}$  required conductance of working point [l/s]  
 $q_{WP}$  **gasflow** of working point [**mbar l/s**]  
 $p_{WP}$  **pressure** of working point [**mbar**]

$$C_{WP} = \frac{q_{WP}}{78.7 \cdot p_{WP}}$$

$C_{WP}$  required conductance of working point [l/s]  
 $q_{WP}$  **gasflow** of working point [**sccm**]  
 $p_{WP}$  **pressure** of working point [**Torr**]

- Out of these calculated conductance values choose the lowest.

$$C_R = \min(C_{WP1}, C_{WP2}, \dots, C_{WPN})$$

$C_R$  required lower conductance [l/s]  
 $C_{WPx}$  required conductance of working points [l/s]



To make sure that the valve is capable to control the most extreme working point verify that  $C_R \geq C_{min}$  of the valve (refer to «Technical data»).

- Calculate gasflow for learn. Choose the applicable formula depending on units you are familiar with.

$$q_L = \frac{p_{SFS} \cdot C_{min}}{1100}$$

$q_L$  gasflow for learn [**Pa m<sup>3</sup>/s**]  
 $p_{SFS}$  sensor full scale pressure [**Pa**]  
 $C_{min}$  min. controllable conductance of valve [l/s], (refer to «Technical data»)

$$q_L = \frac{p_{SFS} \cdot C_{min}}{1.1}$$

$q_L$  gasflow for learn [**mbar l/s**]  
 $p_{SFS}$  sensor full scale pressure [**mbar**]  
 $C_{min}$  min. controllable conductance of valve [l/s], (refer to «Technical data»)


$$q_L = 71 \cdot p_{SFS} \cdot C_{min}$$

$q_L$  gasflow for learn [**sccm**]  
 $p_{SFS}$  sensor full scale pressure [**Torr**]  
 $C_{min}$  min. controllable conductance of valve [l/s], (refer to «Technical data»)

**Evaluation and exchange of learn data**

*Location: CPA/Navigation/Adaptive Learn Data*


The window shows the pressure position curve of the stored data in the learning banks  
 With the menu buttons it is possible to exchange data between learn banks and between valves.





### 5.3.3.3 Tuning

Normally the default settings will result in good pressure control performance. For some applications tuning may be required to improve performance. The tuning procedures for each parameter (grey boxes) and its default values are described separately below. Strictly keep the procedure order.



## Gain Factor adjustment

The Gain Factor effects: **Stability, Response time**

Adjustment range is from 0.0001 to 100.0

- Higher gain results in: faster response, higher over- undershoot of pressure
- Lower gain results in: slower response, lower over- undershoot of pressure

Adjustment procedure:

1. Start with Gain Factor 1.0
2. Open valve.
3. Control a typical pressure / flow situation.
4. Repeat from step 2 with lower (higher) Gain Factors until optimal pressure response is achieved and stability is ok.



Normally adjustments down to Gain Factors of 0.1 should lead to good results. Otherwise you may need to improve sensor connection. Refer to «Requirements to sensor connection».

## Sensor Delay adjustment

Sensor Delay adjustment effects: **Stability**

Adjustment range is from 0.0 to 1.0sec

Pipes and orifices for sensor attachment delay response time and so badly impact pressure control stability.

By adapting this parameter to the approximate delay time stability problems can be reduced. But control response time will be slowed down by this measure.



Whenever possible sensors should be attached to the chamber according to «Requirements to sensor connection». This is the most effective measure against stability issues. If your gauge attachment fulfills these criteria do not use this parameter.

Adjustment procedure:

1. Start with Gain Factor 1.0 and sensor delay 0s.
2. Open valve.
3. Control a typical pressure / flow situation.
4. Repeat from step 2 with higher sensor delays until best possible stability is achieved.
5. Adjustment Gain Factor again. Refer to «Gain factor adjustment».


### Setpoint Ramp adjustment

Setpoint Ramp effects: **Undershoot of pressure, Response time**

Note: The ramp is described in detail in capital Pressure Ramp.

This parameter defines the time that is used to decrease / raise pressure between 2 setpoints. Especially in pressure decrease situations at low flows pressure response can be improved much by adapting setpoint ramp time.

#### Pressure chart



Choose the applicable formula depending on units you are familiar with.

$t$	-	Setpoint Ramp
$P_{SF5}$	-	Pressure at Sensor full scale
$P_{START}$	-	Pressure at start of controlling a pressure step
$P_{END}$	-	Certain pressure, which should be regulated

Adjustment procedure:

1. Start with optimal Gain Factor and sensor delay time according to preceding tuning steps.
2. Control a typical pressure / flow situation.
3. Control a lower pressure.
4. Repeat from step 2 with longer setpoint ramps until best response is achieved.
5. Verify pressure control response for a setpoint raise situation.



In case a long ramp time is required to get optimal performance for pressure decrease situations it may be of advantage to apply different settings for decrease / raise control situations.

## Pressure Control Speed adjustment

Valve speed effects: **Response time**

Adjustment range is from 0.001 to 1.0  
Default value is 1.0

Location: CPA/Navigation/Parameters: Pressure Control.Pressure Control Speed

This parameter effects valve plate actuating speed.  
Speed adjustment is effective for PRESSURE CONTROL and POSITION CONTROL.



Normally best pressure control response is achieved with maximum Pressure Control Speed. In particular applications it may be of advantage to have a slower valve response.  
OPEN and CLOSE are always done with maximum speed.

Adjustment procedure:

1. Use optimal Gain Factor, sensor delay time and setpoint ramp according to preceding tuning steps.
2. Open valve.
3. Control a typical pressure / flow situation.
4. Repeat from step 2 with slower Pressure Control Speed until required response is achieved.

Required information for support:

- Go to 'Tools / Create Diagnostic File' in 'Control Performance Analyzer' and save file
- Pressure / flow / gas conditions to be controlled
- Chamber volume
- Pumping speed (l/s) and pump type (e.g. turbo pump)
- System description
- Problem description

Send diagnostic file with and all required information to [tuning-support@vat.ch](mailto:tuning-support@vat.ch)

### 5.3.4 PI algorithm

This control algorithm may be used for downstream or upstream pressure control depending on configuration.

#### 5.3.4.1 Control Parameter

*Location: CPA/Navigation/Parameters: Pressure Control.Controller x,Control Settings*

Parameter	Description
<b>P-Gain</b>	The <b>P-Gain</b> is the proportional factor of the fixed control algorithm. A higher P-Gain results in faster response, higher over- / undershoot of pressure.
<b>I-Gain</b>	The <b>I-Gain</b> is the integral factor. The <b>I-Gain</b> helps to reach the target pressure exactly.
<b>Pressure Scale</b>	Linear Logarithmic    Recommended if the pressure control extends over several decades. In most cases, the sensor used is a logarithmic sensor anyway.
<b>Direction</b>	The <b>Control Direction</b> defines the type of application, if the valve is mounted in downstream or upstream. Downstream means the valve is after the chamber and before the pump. Upstream, valve is mounted before chamber and pump.

### 5.3.4.2 Tuning

The PI parameters of the pressure controller require correct adjustment. These parameters must be set once during system setup and are stored in the device memory which is power fail save. Based on the PI controller configuration, the valve is able to run fast and accurate pressure control cycles. The PI parameters can be evaluated using below instruction.



- In downstream control mode valve will move towards open when current pressure is higher than set point.
- In upstream control mode valve will move towards close when current pressure is higher than set point.

#### Introduction

PI controller mode is used if for any reason (e.g. too long system time constant) the adaptive control mode does not provide satisfying control performance.

In PI controller mode the parameters P-Gain and I-Gain have to be set according to the systems characteristics. The best set of parameters can be found by using the empiric method below.

#### Pressure and gas flow for optimization

A PI controller delivers the best results for a certain working point (pressure/gas flow). If there is only one working point, this pressure and gas flow has to be used for optimizing P and I-Gain. If there are several working points that have to be covered, the pressure for optimizing is the medium pressure between highest and lowest pressure to be controlled, the gas flow for optimizing is the highest flow out of all working points.

Two different pressure set points are necessary for optimization.

Set point 1 (SP1) is the pressure for optimizing as determined above.

Set point 2 (SP2) is about 10 - 20% lower than SP1.

Example: pressure range: 4 – 10 Torr

Flow range: 2 – 4 slm

Pressure set points and gas flow for optimization:

SP1 = 7 Torr

SP2 = 6 Torr

Gas flow = 4 slm

## Optimizing P-Gain


While optimizing P-Gain, the gas flow determined above has to be constant all the time.

Start optimization with P-Gain set to 1.0 and I-Gain set to 0.0.

Set chamber pressure to SP2, wait until the pressure is stable. Set pressure to SP1. If the transition from SP2 to SP1 results in a significant pressure over shoot or even does not stabilize at all, the P-Gain is too high. If there is no over shoot and the pressure reaches SP1 asymptotically and very slow, P-Gain is too low.

The optimal P-Gain value is found if the transition from SP2 to SP1 results in a slight pressure over shoot. It does not matter if there is still a deviation between SP1 and actual pressure.

Example:



### Optimizing I-Gain


While optimizing I-Gain, the gas flow determined above has to be constant all the time.

Start with P-Gain set to half of the value found when optimizing P-Gain and set I-Gain to 1.0. Keep the P-Gain constant.

Set chamber pressure to SP2, wait until the pressure is stable. Set pressure to SP1. If the transition from SP2 to SP1 results in a significant pressure overshoot or if the valve position does not stabilize, I-Gain is too high. If the transition results in a slow asymptotical pressure rise and there is still a constant deviation to SP2, the I-Gain is too low.

The optimal value for I-Gain is found if the transition from SP2 to SP1 result in just a slight pressure overshoot, a stable valve position and the actual pressure matches SP2 exactly.

Example:



**Check control performance over the whole control range with parameters above.**

Required information for support:

- Go to 'Tools / Create Diagnostic File' in 'Control Performance Analyzer' and save file
- Pressure / flow / gas conditions to be controlled
- Chamber volume
- Pumping speed (l/s) and pump type (e.g. turbo pump)
- System description
- Problem description

Send diagnostic file with and all required information to [tuning-support@vat.ch](mailto:tuning-support@vat.ch)



### 5.3.4.3 Soft Pump/Vent algorithm

This control algorithm may be used to control pressure ramps during pump down or venting the chamber. This is a modified PI controller that has been optimized to start up very gently when the valve is opened.

### 5.3.4.4 Control Parameter

*Location: CPA/Navigation/Parameters: Pressure Control.Controller x,Control Settings*

Parameter	Description
<b>P-Gain</b>	The <b>P-Gain</b> is the proportional factor of the fixed control algorithm. A higher P-Gain results in faster response, higher over- / undershoot of pressure.
<b>I-Gain</b>	The <b>I-Gain</b> is the integral factor. The <b>I-Gain</b> helps to reach the target pressure exactly.
<b>Pressure Scale</b>	Linear Logarithmic    Recommended if the pressure control extends over several decades. In most cases, the sensor used is a logarithmic sensor anyway.
<b>Direction</b>	The <b>Control Direction</b> defines the type of application, if the valve is mounted in downstream or upstream. Downstream means the valve is after the chamber and before the pump. Upstream, valve is mounted before chamber and pump.
<b>Ramp</b>	Only the ramp makes the soft pump or soft vent... See chapter «Pressure Ramp»

### 5.3.4.5 Tuning

#### Optimizing P-Gain

Start optimization with P-Gain set to 0.1 and I-Gain set to 0.0.

The control routine has to be controlled as follows:

- Move control valve into close position
- Start pump down by opening the pump isolation valve or starting the pump
- Send the pressure set point to the valve controller.

While pumping/venting the chamber pressure and valve position should be data logged to compare the actual curve with the ideal straight pump/venting line.

If the pressure follows the ideal pump/venting line with significant delay, the P-Gain is too low.

If the pressure oscillates around the ideal pump/venting line or if the valve position oscillates, P-Gain is too high.

P-Gain is optimized if the pressure follows the ideal pump down line closely and the valve position is not oscillating at all.


### Optimizing I-Gain

Start with P-Gain set to half of the value found when optimizing P-Gain and set I-Gain to 1.0. Keep the P-Gain constant.

If the pressure follows the ideal pump/venting line with significant delay, the I-Gain is too low. If the pressure oscillates around the ideal pump/venting line or if the valve position oscillates, I-Gain is too high.

I-Gain is optimized if the pressure follows the ideal pump down line closely and the valve position is not oscillating at all.

Example:



### Optimizing I-Gain

I-Gain is responsible to reach the setpoint. If reaching setpoint is not important (e.g. setpoint is 0) leave the I-Gain at 0. Otherwise start with P-Gain set to half of the value found when optimizing P-Gain and set I-Gain to 0.1. Keep the P-Gain constant. Start again the pump down. Check how the pressure reaches the setpoint:

If the setpoint is reached too slowly increase I-Gain  
 If there is an undershoot increase I-Gain


Required information for support:

- Go to 'Tools / Create Diagnostic File' in 'Control Performance Analyzer' and save file
- Pressure / flow / gas conditions to be controlled
- Chamber volume
- Pumping speed (l/s) and pump type (e.g. turbo pump)
- System description
- Problem description

Send diagnostic file with and all required information to [tuning-support@vat.ch](mailto:tuning-support@vat.ch)

### 5.3.5 Pressure Ramp

Basically, the pressure ramp is used to limit the rate of pressure change.



#### 5.3.5.1 Configuration

*Location: CPA/Navigation/Parameters: Pressure Control.Controller x.Ramp*

Parameter	Description
<b>Enable</b>	Activate / Deactivate pressure target ramp
<b>Mode</b>	0:Use <b>Ramp Time</b> 1:Use <b>Ramp Slope</b> <span style="float: right;">See description below</span>
<b>Time</b>	Target reach time in seconds (Used if <b>Mode</b> = 0)
<b>Slope</b>	Limit the rate of pressure change in pressure per seconds (Used if <b>Mode</b> = 1)
<b>Type</b>	0:Linear 1:Logarithmic 2:Exponential
<b>Start Value</b>	0:Previous Ramp Value 1:Actual Pressure Value


5.3.5.2 Mode

**Time**

Unit: seconds

Time is constant, slope varies

Example: 2 sec




**Slope**

Unit: Pressure / seconds


Slope is constant, time varies

Example: 10mTorr/second




5.3.5.3 Type


**Linear**



**Logarithmic**




**Exponential**



**5.3.5.4 Applications Examples**


**Soft pump**

Ramp Mode = Time  
 Ramp Time = 100 sec  
 Ramp Type = Linear  
 Target Pressure = 0




**Minimize pressure over- or undershoots**

New Target Pressure without pressure ramp




New Target Pressure with pressure ramp



**Smoothing a staircase**

Pressure ramp with new target pressure to the valve every second is smoothed by a 1 sec internal ramp  
 Ramp Time = 1sec



### 5.3.6 Profile Ramp


Profile Ramp is a **Target Pressure** ramp that depends on pressure ranges (segments). It is mainly used to create soft pumping or soft venting profiles.

To design a profile, the segments (pressure ranges) must be defined. A segment is defined by the pressure **Threshold** and the **Slope**. It is possible to define up to 10 segments.

Example: Ramp Profile with 3 segments

Segment Nr	Threshold mBar*	Resulting Segment mBar*	Slope mBar*/sec
1	1000	500 to 1000	50
2	500	200 to 500	100
3	200	0 to 200	200

Result is a Target Pressure Ramp (**Target Pressure Used**) with different slopes depending on pressure ranges:




Parameters:


Location: CPA/Navigation/Parameters: Pressure Control.General Settings.Profile Ramp

Parameter	Description
<b>Enable</b>	Switches on/off the function
<b>Threshold Mode</b>	Defines which pressure the threshold refers to

**Actual Pressure** Change happens if **Actual Pressure** reaches the **Threshold**




**Target Pressure Used** Change happens if **Target Pressure Used** reaches the **Threshold**



<b>Ramp Type</b>	Defines the shape of the ramp <a href="#">Linear</a> <a href="#">Logarithmic</a> <a href="#">Exponential</a>
------------------	---


<b>Actual Slope</b>	Show the actual use slope during pressure control in mBar*/sec.
---------------------	---

<b>Controller Selector Bitmap</b>	Determines which Controller uses the profile ramp. When a Controller is selected, the ramp is no longer used in the controller itself. Therefore the ramp is greyed out in the CPA.
-----------------------------------	--



<b>Segment Selector Bitmap</b>	Defines which segments is used for the Profile Ramp.
--------------------------------	--

**Segment x Threshold** This is the upper limit of the segment. The lower limit is defined by the next lower **Threshold**, or the lower limit is 0 if there is no lower **Threshold**.  
 If the value exceeds the top threshold, the slope value of the top segment is used (Segment 1 in below example)



**Segment x Slope** Defines the slope (mBar\*/sec) in the segment

\* Unit adjustable





### 5.3.7 Automated Controller Selector

With the 4 Controllers it is possible to define different pressure control settings. The Automated Controller Selector can select one of the 4 Controllers depending on Target Pressure (**Mode: *Threshold***) or Up-Down Control (**Mode: *Pressure Direction***)

**Mode: *Threshold***  
**Threshold Condition: *Lower or Equal***  
**Controller Selector changes when the Target Pressure exceeds or falls below a Threshold value**

Mode: **Threshold**

Controller Selector Bitmap: 15

Threshold Condition: **Lower or Equal**

Controller 1 Threshold: [mbar] 100

Controller 2 Threshold: [mbar] 200

Controller 3 Threshold: [mbar] 400

Controller 4 Threshold: [mbar] 1000

**Threshold Condition: *Equal***  
**Controller Selector changes only when the Target Pressure is equal to a Threshold value**

Mode: **Threshold**

Controller Selector Bitmap: 15

Threshold Condition: **Equal**

Controller 1 Threshold: [mbar] 100

Controller 2 Threshold: [mbar] 200

Controller 3 Threshold: [mbar] 400

Controller 4 Threshold: [mbar] 1000

**Mode: *Pressure Direction***  
**Controller Pressure Rising: *Controller 1***  
**Controller Pressure Falling: *Controller 2***  
**Controller Selector changes depending on whether Target Pressure is rising or falling**

Mode: **Pressure Direction**

Controller Pressure Rising: **Controller 1**

Controller Pressure Falling: **Controller 2**

Parameter:

Location: CPA/Navigation/Parameters: Pressure Control.General Settings.Automated Controller Selector

Parameter	Description
<b>Enable</b>	Switches on/off the function
<b>Mode</b>	<a href="#">Threshold</a> <a href="#">Pressure Direction</a>
<b>Controller Selector Bitmap</b>	Used if <b>Mode</b> = <a href="#">Threshold</a> Defines which controllers are automatically selected
<b>Threshold Condition</b>	Used if <b>Mode</b> = <a href="#">Threshold</a> <a href="#">Lower or Equal</a> <a href="#">Equal</a> The Thresholds are related to <b>Target Pressure</b>
<b>Controller 1 Threshold</b>	Used if <b>Mode</b> = <a href="#">Threshold</a>
<b>Controller 2 Threshold</b>	The Thresholds are related to <b>Target Pressure</b>
<b>Controller 3 Threshold</b>	
<b>Controller 4 Threshold</b>	
<b>Controller Pressure Rising</b>	Used if <b>Mode</b> = <a href="#">Pressure Direction</a>
<b>Controller Pressure Falling</b>	Select one Controller for up control and one for down control <a href="#">Controller 1</a> <a href="#">Controller 2</a> <a href="#">Controller 3</a> <a href="#">Controller 4</a>

### 5.3.8 Control Position Restriction

Location: CPA/Navigation/Parameters: Pressure Control.General Settings.Control Position Restriction

Parameter	Description
<b>Enable</b>	False True
<b>Minimum Control Position</b>	Defines the lowest position during pressure control
<b>Maximum Control Position</b>	Defines the highest position during pressure control
<b>Restriction Active</b>	False True

### 5.3.9 Store Control Parameter Volatile

Used when the control parameters are changed frequently during the process and it is not useful to store the value in the non-volatile memory each time (the lifetime of the non-volatile value is 1 million memory cycles).

Only effective on the interface, the settings via CPA are always stored in non-volatile memory

Location: CPA/Navigation/Parameters: Pressure Control.General Settings

Parameter	Description
<b>Store Control Parameter Volatile</b>	False True

## 5.4 Position Control

### 5.4.1 Parameter

*Location: CPA/Navigation/Parameters: Position Control*

Parameter	Description
<b>Actual Position</b>	Position of the valve plate Range depends on Position Scaling setting (on Interface and CPA)
<b>Target Position</b>	Desired position of the valve plate Range depends on Position Scaling setting (on Interface and CPA)
<b>Position Control Speed</b>	Speed of the valve in Control Mode Position 0.001 .. 1.0 (Full speed)
<b>Ramp</b>	See below

### 5.4.2 Position Ramp



#### 5.4.2.1 Configuration

*Location: CPA/Navigation/Parameters: Position Control.Ramp*

Parameter	Description
<b>Enable</b>	Activate / Deactivate position ramp
<b>Mode</b>	0:Use <b>Ramp Time</b> 1:Use <b>Ramp Slope</b> <span style="float: right;">See description below</span>
<b>Time</b>	Target reach time in seconds (Used if <b>Mode</b> = 0)
<b>Slope</b>	Limit the rate of position change per second (Used if <b>Mode</b> = 1)
<b>Type</b>	0:Linear 1:Logarithmic 2:Exponential


5.4.2.2 Mode

**Time**

Unit: seconds

Time is constant, slope varies

Example: 2 sec




**Slope**

Unit: %\* / seconds

Slope is constant, time varies


Example: 10% / sec




\* Unit adjustable

5.4.2.3 Type


**Linear**



**Logarithmic**



**Exponential**



5.5 Operation under increased temperature

	CAUTION
	<p><b>Hot valve</b></p> <p>Heated valve may result in minor or moderate injury.</p> <p>Do not touch valve and heating device during operation. Once heating is switched off (valve and system) await until the valve is cooled down complete before doing any work.</p>



This valve may be operated in the temperature range mentioned product data sheet.

	WARNING
	<p><b>O-ring sticking</b></p> <p>Due to the sticking properties of elastomer O-rings at high temperature, operator/integrator must ensure the vacuum product settled at the same temperature prior to opening as it was when it was closed otherwise there is a risk of damage to the O-ring.</p>

## 6 Trouble shooting

### 6.1 Warnings



A warning does not lead to an interruption of valve operation.

*Location: CPA/Parameters: System.Services*

Parameter	Description		
<b>Warning Bitmap</b>	Bit	Hex	Description
	0	1	No learn data available for adaptive control
	1	2	Position indicator signal of the external isolation valve incorrect.
	2	4	No Sensor Active
	3	8	PFO Not Ready
	4	16	Cluster Slave Offline
	6	40	Fieldbus Data Not Valid
	8	256	Compressed Air Not Falling when valve close
	9	512	Compressed Air Too Low
	10	1024	Compressed Air Too High
	12	4096	Fan stall alarm

Failure	Check	Action
Display does not light up	- 24 V power supply	- Connect valve to power supply according to 'Power, ground and sensor connection' and make sure that power supply is working.
Remote operation does not work	- Local operation via service port active	- Switch to remote or locked operation Refer to 'Remote and local operation'
	- Safety mode active Check for S on display	- Check 'Drive Power Enable Switch' Refer to 'Power, ground and sensor connection'
	- Interlock mode active Check for I on display	- Check Digital Input Refer to 'Power connector IO' → 'Digital Input'
POSITION CONTROL does not work	- Safety mode active Check for S on display	- Check 'Drive Power Enable Switch' Refer to 'Power, ground and sensor connection'
	- Interlock mode active Check for I on display	- Check Digital Input Refer to 'Power connector IO' → 'Digital Input'
	- POSITION CONTROL selected, check for A on display?	- Select POSITION CONTROL mode. Refer to 'Control Mode' in 'EtherCAT' interface
Pressure reading is wrong	- Sensor connection	- Refer to 'Power, ground and sensor connection'
Pressure reading is negative	- ZERO done?	- Perform ZERO when base pressure is reached. Refer to 'Pressure Sensor' → 'Zero Adjust'
	- Does sensor power supply provide enough power for sensor(s)?	- Verify sensor supply voltage.
ZERO does not work	- ZERO disabled?	- Enable ZERO. Refer to 'Pressure Sensor' → 'Zero Adjust'
	- Sensor voltage shifting?	- Wait until sensor does not shift any more before Performing ZERO.
Pressure is not '0' after ZERO	- System pumped to base pressure?	- OPEN VALVE and bring chamber to base pressure before performing ZERO.
	- Sensor offset voltage exceeds ±1.4V	- Adjust the offset direct at the sensor - Check function of the sensor.
PRESSURE CONTROL does not work	- PRESSURE CONTROL selected, check for P on display?	- Select PRESSURE CONTROL mode. Refer to 'Control Mode' in 'EtherCAT' interface
	- LEARN done?	- Perform LEARN. Refer to 'Pressure control' → 'Adaptive algorithm' → 'Learn'
	- Sensor signal ok?	- Refer to 'Pressure Sensor'
	- Pressure control setup done	- Refer to 'Pressure control'
PRESSURE CONTROL not optimal	- LEARN successfully done?	- Perform LEARN. Check 'Status' and 'Warning Info' in 'Pressure control' → 'Adaptive algorithm' → 'Learn'
	- ZERO performed before LEARN?	- Perform ZERO then repeat LEARN. Refer to 'Pressure Sensor' → 'Zero Adjust'
	- Was gas flow stable during LEARN?	- Repeat LEARN with stable gas flow. Refer to 'Pressure control' → 'Adaptive algorithm' → 'Learn'
	- Tuning done?	- Tune valve for application. Refer to the tuning sections in 'Pressure Control'
	- Is sensor range suited for application?	- Use a sensor with suitable range (controlled pressure should be >3% and < 98% of sensor full scale).
	- Noise on sensor signal?	- Make sure a shielded sensor cable is used.

## 6.2 Errors



If valve is in Control Mode Error, movement is no longer possible.

The following parameters provide information about the cause of the error:

*Location: CPA/Parameters: System.Services*

Parameter	Description
<b>Error Bitmap</b>	Information about the types of errors. Details below.
<b>Error Number</b>	Information about the error component. Details below. Also shown on the controller display when active.
<b>Error Code</b>	Information about the different error states. Details below. Also shown on the controller display when active.



If you need any further information, please contact one of our service centers.  
You will find the addresses on our website: [www.vatvalve.com](http://www.vatvalve.com)

The following information is required for VAT to analyze the error case:

- Diagnostic File: CPA → Tools → Diagnostic File
- Load Error Data: CPA → Tools → Trace Log → Mode Load Error Data → Start

### 6.2.1 Error Recovery

To leave the error state, the **Error Recovery** or **Restart Controller** can be used:

*Location: CPA/Parameters: System.Services*

Parameter	Description
<b>Restart Controller</b>	Emulates a power cycle of the valve
<b>Error Recovery</b>	Attempts to reset the Control Mode Error without restarting the valves



Create a diagnostic file before recovery or restart if the error is to be analyzed by VAT

### 6.2.2 Error Bitmap

Parameter	Description		
<b>Error Bitmap</b>	Bit	Hex	Description
	0	1	Homing Position Error
	1	2	Homing Not Running
	2	4	Homing Error State
	3	8	Operation Position Error
	4	10	Operation Not Running
	5	20	Operation Error State
	12	1000	Other Component
	30	40000000	General
	31	80000000	Internal

### 6.2.3 Error Number



Error numbers are three-digit decimal numbers (**xyz**) whereas:

x = component	y = mode	z = error type
<b>1</b> = All Motor Units <b>2</b> = Motor Unit 1 <b>3</b> = Motor Unit 2 <b>4</b> = Motor Unit 3 <b>8</b> = Other	<b>0</b> = Homing <b>2</b> = Operation Mode <b>8</b> = Other	<b>0</b> = Position Error <sup>1)</sup> <b>1</b> = Not running: No communication with component <b>x</b> <b>2</b> = Error State: component <b>x</b> is running but in Status Error <b>8</b> = Other

### 6.2.4 Error Code

<sup>1)</sup> Mechanical movement problem:

- Check for differential pressure
- Remove foreign object in movement area
- Eliminate tight movement
- Repair mechanical failure

Code	Description	Solution
1	No valve connected	Connect valve controller to the valve
2	Nonvolatile memory failure	Replace valve controller
3	Analog digital converter of sensor input failure	Replace valve controller
4	Initialization of motion controller failed	Wrong motion controller firmware version → Update motion controller firmware
5	Encoder index pulse not found	<ul style="list-style-type: none"> <li>• <sup>1)</sup></li> <li>• Encoder failure</li> <li>• O-ring sticking</li> </ul>
6	Initialization of interface module failed	<ul style="list-style-type: none"> <li>• Fieldbus: Valve firmware does not support interface type → Update valve firmware</li> <li>• Wrong interface firmware version → Update interface firmware</li> </ul>
7	Initialization of external drive EEPROM failed	Check cables
10	Closing position can't be reached	<sup>1)</sup>
11	Homing position can't be reached	<ul style="list-style-type: none"> <li>• <sup>1)</sup></li> <li>• Plate not mounted</li> </ul>
12	Motion controller: Internal voltage error	Check power supply
13	Motion controller: Internal error temperature	Check for a heat accumulation
14	Motion controller: Unexpected behavior	Contact vat support <ul style="list-style-type: none"> <li>• Axis inverted</li> <li>• Encoder not connected</li> <li>• Break not released</li> </ul>
15	Motion controller: Target position can't be reached	<ul style="list-style-type: none"> <li>• <sup>1)</sup></li> <li>• Current Settings</li> </ul>
16	Motion controller: Position minimal conductance cannot be reached	<ul style="list-style-type: none"> <li>• <sup>1)</sup></li> <li>• Check Plate and Seal ring</li> <li>• Check Parameter "Isolation Position Enter [r]"</li> </ul>
17	Motion controller: Position to push back the Differential Plate cannot be reached	<ul style="list-style-type: none"> <li>• <sup>1)</sup></li> <li>• Check Different Plate</li> <li>• Check Parameter "Differential Plate Push Back Position [r]"</li> </ul>
18	Motion controller: Minimal isolation position cannot be reached	<ul style="list-style-type: none"> <li>• <sup>1)</sup></li> <li>• Check Plate and Seal ring</li> <li>• Check Parameter "Isolation Position [r]"</li> </ul>
20	Break slippery detected	Replace actuator



Code	Description	Solution
30	SFV: Motion controller failure in master-slave communication	Contact vat support
40	Compressed air error	Check compressed air
42	Power supply, low voltage detected	Check if power supply is ok and is able to deliver needed power
96	SFV: Position deviation axis1 to axis2 at homing procedure	<ul style="list-style-type: none"> <li>• 1)</li> <li>• O-ring sticking</li> </ul>
97	SFV: Position deviation axis1 to axis2 at operating	1)
98	Position error during closing procedure	1)
99	Position error at operating	1)
200	Valve configuration error, not possible to operate the valve with these configuration	Contact VAT support
701	Wrong ident code axis 1	Check wiring
702	Wrong ident code axis 2	
703	Wrong ident code axis 2 AND axis 1	
704	Wrong ident code axis 3	
705	Wrong ident code axis 3 AND axis 1	
706	Wrong ident code axis 3 AND axis 2	
707	Wrong ident code axis 3 AND axis 2 AND axis 1	
707	Do not operating mode active	

### 6.3 Troubleshooting List

Failure	Check	Action
Display does not light up	- 24 V power supply	- Connect valve to power supply according to 'Power, ground and sensor connection' and make sure that power supply is working.
Remote operation does not work	- Local operation via service port active	- Switch to remote or locked operation Refer to 'Remote and local operation'
	- Safety mode active Check for S on display	- Check 'Drive Power Enable Switch' Refer to 'Power, ground and sensor connection'
	- Interlock mode active Check for I on display	- Check Digital Input Refer to 'Power connector IO' → 'Digital Input'
POSITION CONTROL does not work	- Safety mode active Check for S on display	- Check 'Drive Power Enable Switch' Refer to 'Power, ground and sensor connection'
	- Interlock mode active Check for I on display	- Check Digital Input Refer to 'Power connector IO' → 'Digital Input'
	- POSITION CONTROL selected, check for A on display?	- Select POSITION CONTROL mode. Refer to 'Control Mode' in 'EtherCAT' interface
Pressure reading is wrong	- Sensor connection	- Refer to 'Power, ground and sensor connection'
Pressure reading is negative	- ZERO done?	- Perform ZERO when base pressure is reached. Refer to 'Pressure Sensor' → 'Zero Adjust'
	- Does sensor power supply provide enough power for sensor(s)?	- Verify sensor supply voltage.
	- ZERO disabled?	- Enable ZERO. Refer to 'Pressure Sensor' → 'Zero Adjust'
ZERO does not work	- Sensor voltage shifting?	- Wait until sensor does not shift any more before Performing ZERO.
	- System pumped to base pressure?	- OPEN VALVE and bring chamber to base pressure before performing ZERO.
Pressure is not '0' after ZERO	- Sensor offset voltage exceeds ±1.4V	- Adjust the offset direct at the sensor - Check function of the sensor.
	- PRESSURE CONTROL selected, check for P on display?	- Select PRESSURE CONTROL mode. Refer to 'Control Mode' in 'EtherCAT' interface
PRESSURE CONTROL does not work	- LEARN done?	- Perform LEARN. Refer to 'Pressure control' → 'Adaptive algorithm' → 'Learn'
	- Sensor signal ok?	- Refer to 'Pressure Sensor'
	- Pressure control setup done	- Refer to 'Pressure control'
	- LEARN successfully done?	- Perform LEARN. Check 'Status' and 'Warning Info' in 'Pressure control' → 'Adaptive algorithm' → 'Learn'
PRESSURE CONTROL not optimal	- ZERO performed before LEARN?	- Perform ZERO then repeat LEARN. Refer to 'Pressure Sensor' → 'Zero Adjust'
	- Was gas flow stable during LEARN?	- Repeat LEARN with stable gas flow. Refer to 'Pressure control' → 'Adaptive algorithm' → 'Learn'
	- Tuning done?	- Tune valve for application. Refer to the tuning sections in 'Pressure Control'
	- Is sensor range suited for application?	- Use a sensor with suitable range (controlled pressure should be >3% and < 98% of sensor full scale).
	- Noise on sensor signal?	- Make sure a shielded sensor cable is used.

## 7 Maintenance

	<p style="text-align: center;"><b>⚠ WARNING</b></p> <p><b>Unqualified personnel</b> Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.</p>
	<p style="text-align: center;"><b>⚠ WARNING</b></p> <p><b>Valve opening</b> Risk of serious injury. Human body parts must be kept out of the valve opening and away from moving parts. Disconnect power on controller before doing any work.</p>
	<p style="text-align: center;"><b>⚠ CAUTION</b></p> <p><b>Hot valve</b> Heated valve may result in minor or moderate injury. Do not touch valve and heating device during operation. Once heating is switched off (valve and system) await until the valve is cooled down complete before doing any work.</p>
	<p style="text-align: center;"><b>NOTICE</b></p> <p><b>Contamination</b> Gate and other parts of the valve must be protected from contamination. Always wear clean room gloves when handling the valve.</p>

### 7.1 Maintenance intervals

Under clean operating conditions, the valve does not require any maintenance during the specified cycle life. Contamination from the process may influence the function and requires more frequent maintenance.

Before carrying out any maintenance, please contact VAT. It has to be individually decided whether the maintenance can be performed by the customer or has to be carried out by VAT. Please write down the fabrication number of the valve before contact VAT. Refer to chapter «Identification of product» for fabrication number.

## 7.2 Maintenance procedures

Two maintenance procedures are defined for this valve. This are:

- Replacement of shaft feedthrough seals and valve cleaning. Refer to chapter: «Replacement of rotary feedthrough».
- Replacement of Option board. Refer to chapter: «Replacement of Option board»



Required frequency of cleaning and replacement of seals is depending on process conditions.

VAT can give the following recommendations for preventive maintenance:

Replacement of	unheated <sup>1)</sup>	heated $\leq 80$ °C <sup>1)</sup>	heated $> 80$ °C <sup>1)</sup>
<b>Rotary feedthrough seals</b>	2'000'000 cycles	6 months but max. 2'000'000 cycles	3 months but max. 2'000'000 cycles
<b>Plate O-ring / Plate vulcanized</b>	250'000 closing / opening	6 months but max. 250'000 cycles	3 months but max. 250'000 cycles
<b>Plate O-ring / Plate vulcanized DN 63 - 100 mm</b>	100'000 closing / opening	6 months but max. 100'000 cycles	3 months but max. 100'000 cycles



<sup>1)</sup> Those figures are reference values for clean conditions under various temperatures. These values do not include any impact of the process. Therefore preventive maintenance schedule has finally to be checked for the actual process conditions.



Below pictures are sample pictures. Although there may be different variants of the valve, the assembly procedure stays the same for all these variants with the differences shown in the table below.



ISO K (DN 40-50)



ISO\_F (DN 63-100)



Plate with O-ring
















Plate vulcanized









### 7.2.1 Replacement of vulcanized plate or plate with O-ring

#### Required tools

- Allen wrench 3mm for DN 40-63mm
- Allen wrench 4mm for DN 80-100mm
- O-ring removal tool (see chapter Accessories)
- Vacuum grease (see chapter spare parts)
- Cleanroom wipes

Description		Required tool
1. Vent vacuum system on both sides of the valve. 2. Move the plate to position 30% open. 3. Disconnect electrical POWER connector at valve and remove valve from vacuum system.  <b>Attention!</b> Electrical power is needed for plate adjustment  Take care to the sealing surface!		
4. Unfasten and remove the 2 or 3 fastening screws		<ul style="list-style-type: none"> <li>• Allen wrench 3mm for DN 40-63mm</li> <li>• Allen wrench 4mm for DN 80-100mm</li> </ul>
5. Push the plate a little down		
6. Remove the plate on the other side of shaft		

Description		Required tool
<p>7. For vulcanized plates, please skip steps 8-12 for O-ring replacement and use a new vulcanized plate instead. Lubricate the new vulcanized plate with 0.025g / 0.0125 ml vacuum grease.</p> <p> Pay attention that grease is distributed constantly over the whole seal circumference</p>		Vacuum grease
<p>8. For plate O-ring exchange, skip step 7 and remove the plate O-ring instead</p> <p> Replace the plate if necessary</p>		O-ring removal tool
<p>9. Clean the plate and O-ring groove</p> <p> Check the O-ring groove. If there are any scratches in groove, use a new plate. Refer to spare parts for new plate.</p>		Cleanroom wipes soaked with isopropyl alcohol
<p>10. Lubricate the new O-ring with 0.025g / 0.0125 ml vacuum grease</p> <p> Pay attention that grease is distributed constantly over the whole circumference</p> <p>For new O-ring refer to chapter spare parts.</p>		Vacuum grease
<p>11. Place the new O-ring at O-ring groove at one side first. Then move the O-ring in the O-ring groove fully around including the other side</p>		

Description		Required tool
<p>12. Push in the O-ring equally around the plate into O-ring groove.</p> <p> Ensure it is fully and symmetrically inserted.</p>		
<p>13. Place the plate on the shaft in the valve body</p>		
<p>14. Tighten plate screws to block.</p> <p>15. Loosen the plate screws a quarter turn counter clockwise.</p> <p> Plate is now movable on shaft and ready to sliding into valve seat.</p>		<ul style="list-style-type: none"> <li>• Allen wrench 3mm for DN 40-63mm</li> <li>• Allen wrench 4mm for DN 80-100mm</li> </ul>
<p>16. Connect electrical POWER connection at valve</p> <p><b>Attention!</b> Valve does synchronize automatically and moves the plate into sit of valve body (close position).</p> <p>17. Disconnect electrical POWER connection</p>	<p style="text-align: center;"><b>Attention!</b></p>  <p style="text-align: center;">Keep fingers out of the valve opening during plate movement!</p>	
<p>18. Fasten the plate screws with</p> <ul style="list-style-type: none"> <li>• 2 Nm for DN 40- 63 mm</li> <li>• 4 Nm for DN 80 – 100 mm</li> </ul> <p> If some grease on plate surface or valve body clean it with cleanroom wipes</p>		<ul style="list-style-type: none"> <li>• Allen wrench 3mm for DN 40-63mm</li> <li>• Allen wrench 4mm for DN 80-100mm</li> <li>• Cleanroom wipes</li> </ul>






Description		Required tool
19. Reinstall valve into vacuum system according to chapter «Installation» of valve manual		













## 7.2.2 Replacement of shaft feed through seals and valve cleaning







### Required tools






- Allen wrench 2mm / 2.5mm
- Allen wrench 3mm
- O-ring removal tool (see chapter Accessories)
- Isopropyl alcohol
- Cleanroom wipes
- Vacuum grease (see chapter spare parts)





Description		Required tool
<p>1. Vent vacuum system on both sides of the valve.            2. Move the plate to position 50% open.            3. Disconnect electrical POWER connector at valve and remove valve from vacuum system.</p> <p><b>Attention!</b> Electrical power is needed for plate adjustment.</p> <p> Take care to the sealing surface!</p>		
<p>4. Loosen clamp coupling screw</p>		<p>Allen wrench: 2.5 mm</p>
<p>5. Unfasten and remove the 3 fastening screws</p>		<p>Allen wrench: 3mm</p>
<p>6. Remove control and actuating unit from mechanical valve unit</p> <p> If clamp coupling is separated, assemble them at control and actuating unit.</p>		

Description		Required tool
7. For removing the plate and exchanging the plate or O-ring we refer to Steps 4-7 or 4-12 12 of the previous chapter 7.2.1 Replacement of vulcanized plate or plate with O-ring		
8. Unfasten the two (DN40-63) or three (DN80-100) - screws completely		<ul style="list-style-type: none"> <li>• Allen wrench 3mm for DN 40-63mm</li> <li>• Allen wrench 4mm for DN 80-100mm</li> </ul>
9. Remove mechanical unit from valve body		
10. Clean shaft		Cleanroom wipes soaked with isopropyl alcohol


Description		Required tool
11. Remove both O-rings   Check and if required use new O-rings.		Soft tool
12. Clean shaft feed through and the valve body		Cleanroom wipes soaked with isopropyl alcohol
13. Lubricate seal contact surface of valve body with a slight film of 0.025g = 0.0125 ml vacuum grease		Vacuum grease
14. Lubricate seal contact surface of shaft with a slight film of 0.025g = 0.0125 ml vacuum grease		Vacuum grease
15. Lubricate each O-ring with a slight film of 0.025g = 0.0125 ml vacuum grease.		Vacuum grease


Description	Required tool
<p>16. Slide both O-rings onto shaft till the end</p> <p>17. Deposit the following amount of vacuum grease between the O-rings:                      0.075 g = 0.04 ml for DN 40 and DN 50                      0.1 g = 0.05 ml for DN 63, 80,100</p> <p>18. Clean shaft from vacuum grease</p> <p> Make sure there is no residuals from vacuum grease on the shaft.</p>	 <p>Vacuum grease Cleanroom wipes</p>
<p>19. Install mechanical unit into valve body, see picture</p> <p> Make sure the pedestal is aligned to be parallel with the valve body</p>	
<p>20. Fasten and tighten the mounting screws</p> <ul style="list-style-type: none"> <li>• 2x with 2.5 Nm for DN 40-63mm</li> <li>• 3x with 4 Nm for DN 80-100mm</li> </ul>	 <ul style="list-style-type: none"> <li>• Allen wrench 3mm for DN 40-63mm</li> <li>• Allen wrench 4mm for DN 80-100mm</li> </ul>
<p>21. Place the plate on the shaft in the valve body</p>	

Description		Required tool
22. Tighten plate screws to block. 23. Loosen the plat screws a quarter turn counter clockwise so that plate is still movable at shaft.		<ul style="list-style-type: none"> <li>• Allen wrench 3mm for DN 40-63mm</li> <li>• Allen wrench 4mm for DN 80-100mm</li> </ul>
24. Clean the actuating lever   Make sure that there is no grease at actuating lever axis (C)		
25. Assemble valve unit with control and actuating. Push axis (C) into clamp coupling		
26. Tighten mounting screws adequately		Allen wrench: 3mm

Description	Required tool
27. Tighten clamp steel coupling with 1.1 Nm	
28. Connect electrical POWER connection at valve <b>Attention!</b> Valve does synchronize automatically and moves the plate into sit of valve body (close position). 29. Disconnect electrical POWER connection	<p style="text-align: center;"><b>Attention!</b></p>  <p style="text-align: center;">Keep fingers out of the valve opening during plate movement!</p>
30. Fasten the plate screws with <ul style="list-style-type: none"> <li>• 2 Nm for DN 40- 63 mm</li> <li>• 4 Nm for DN 80 – 100 mm</li> </ul>  If some grease on plate surface or valve body clean it with cleanroom wipes	 <ul style="list-style-type: none"> <li>• Allen wrench 3mm for DN 40-63mm</li> <li>• Allen wrench 4mm for DN 80-100mm</li> <li>• Cleanroom wipes</li> </ul>
31. Reinstall valve into vacuum system according to chapter «Installation».	

### 7.2.3 Replacement of Option board

<b>NOTICE</b>	
	<p><b>Electrostatic discharge</b></p> <p>Electronic components could be damage.</p> <p>All work on the control and actuating unit has to be done under ESD protected environment to prevent electronic components from damage.</p>

<b>NOTICE</b>	
	<p><b>Burned connector pins (spark)</b></p> <p>Connector pins or electronic parts could damage, if plugged and unplugged under power.</p> <p>Do not plug or unplug connectors under power.</p>

The option board may or may not be equipped in your valve depending on the order. Refer to page 1 of this manual to check valve version. This board includes the optional modules for the valve which are:

- $\pm 15$  VDC sensor power supply (SPS)
- Power failure option (PFO)

It is available in 3 versions. These are:

- SPS module only
- PFO module only
- SPS and PFO module

The modules may be retrofitted or replaced easily. The battery lifetime of the PFO module depends on the ambient temperature (see below). To assure PFO function the option board must be replaced after battery life has expired. For ordering number of the modules refer to chapter «Spare parts».



If you need any further information, please contact one of our service centers. You can find the addresses on our website: [www.vatvalve.com](http://www.vatvalve.com).




**7.2.3.1 Durability of power fail battery**

The curves in the graph show the estimated life of Ultra Cap PFO in the worst condition (max. sensor load = 1 A, valve heating temperature = 150 °C).

If the SPS is not fully loaded (< 1 A) or heating temperature of valve body is lower than 150 °C, the corresponding life time curve will be somewhere in between the upper and the lower curve.


Therefore please determine the equivalent maintenance period for replacing the Ultra Cap battery (Option board).



This graph shows estimated life of Ultra Cap PFO for reference and not as guaranteed value.

**7.2.3.2 Retrofit / replacement procedure**

View on control and actuating unit:



All boards have a fixed position into control and actuating unit. It is not possible to fit a board in other position as shown in picture above! Do not try out other positions, which maybe destroy the socket of boards!









**Required tools**

- Allen Wrench 2 mm / 2.5mm
- Allen Wrench 3 mm



If you need any further information, please contact one of our service centers. You can find the addresses on our website: [www.vatvalve.com](http://www.vatvalve.com).

Description		Required tool
1. Vent vacuum system on both sides of the valve. 2. Move the plate to position 30% open. 3. Disconnect electrical POWER connector at valve and remove valve from vacuum system. <b>Attention!</b> Electrical power is needed for plate adjustment. Take care to the sealing surface!		Depending on flange screws
4. Unfasten clamp coupling		Allen wrench: 2.5 mm
5. Unfasten the 3 connection bolts and separate valve body from controller		Allen wrench 3 mm

Description	Required tool
<p>6. Replacement of the option board / whole controller</p> <p>Unfasten the two bolts from bottom side and dismount the controller from the actuator unit.</p> <p>The SPS/PFO option board has to be mounted/ dismounted from bottom side of the controller.</p> <p>The Controller and Interface board are fix connected and shall not be dismantled.</p> <p> you have to work on an ESD-protected working space</p> <p> If you need any further information, please contact one of our service centers. You can find the addresses on our website: <a href="http://www.vatvalve.com">www.vatvalve.com</a></p>	 
<p>7. Assemble valve unit with control and actuating. Push axis (C) into clamp coupling</p>	
<p>8. Tighten mounting screws adequately</p>	 <p>Allen wrench 3mm</p>

Description		Required tool
9. Tighten clamp of steal coupling with 1.1 Nm		Allen wrench: 2.5 mm

## 8 Repairs

Repairs may only be carried out by the VAT service staff. In exceptional cases, the customer is allowed to carry out the repairs, but only with the prior consent of VAT.


Please contact one of our service centers. You will find the addresses on our website [www.vatvalve.com](http://www.vatvalve.com).

### 8.1 FPR Service


The VAT customer service can refurbish the product or individual components for you. Wear-sensitive parts are replaced, and the guarantee on the replaced parts is extended.

- a) Select the desired Fixed Price Refurbishment service from our comprehensive service program for the refurbishment.
- b) Contact your assigned sales person or the nearest VAT service center to learn about the options for the product in question. [www.vatvalve.com](http://www.vatvalve.com).

## 9 Dismounting and Storage

	<b>⚠ WARNING</b>
	<b>Unqualified personnel</b> Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.


### 9.1 Dismounting


	<b>NOTICE</b>
	<b>Contamination</b> Gate and other parts of the valve must be protected from contamination. Always wear clean room gloves when handling the valve.

	<b>NOTICE</b>
	<b>Valve in open position</b> Valve body may become damaged if valve gate is in open position. Move valve gate to the closed position before dismounting the valve.

1. Close the valve
2. For dismounting the valve please follow the instructions of chapter: «Installation», however in reverse order.



## 9.2 Storage



<b>NOTICE</b>	
	<p><b>Wrong storage</b></p> <p>Inappropriate temperatures and humidity may cause damage to the product.</p> <p>Valve must be stored at:</p> <ul style="list-style-type: none"><li>– relative humidity between 10% and 70%</li><li>– temperature between +10 °C and +50 °C</li><li>– non-condensing environment</li></ul>


<b>NOTICE</b>	
	<p><b>Inappropriate packaging</b></p> <p>Product may get damaged if inappropriate packaging material is used.</p> <p>Always use the original packaging material and handle product with care.</p>

1. Clean / decontaminate valve.
2. Cover all valve openings with a protective foil.
3. Pack valve appropriately, by using the original packaging material.

## 10 Packaging and Transport

	 <b>WARNING</b>
	<p><b>Unqualified personnel</b></p> <p>Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.</p>


	 <b>WARNING</b>
	<p><b>Harmful substances</b></p> <p>Risk of injury in case of contact with harmful substances. Remove harmful substances (e. g. toxic, caustic or microbiological ones) from valve before you return the valve to VAT.</p>

	<b>NOTICE</b>
	<p><b>Inappropriate packaging</b></p> <p>Product may get damaged if inappropriate packaging material is used. Always use the original packaging material and handle product with care.</p>



- When returning products to VAT, please fill out the VAT form «Declaration of Chemical Contamination of Vacuum Valves and Components» and send it to VAT in advance. The form can be downloaded from our website [www.vatvalve.com](http://www.vatvalve.com) (Section: Services – Aftersales).
- If products are radioactively contaminated, the VAT form «Contamination and Radiation Report» must be filled out. Please contact VAT in advance.
- If products are sent to VAT in contaminated condition, VAT will carry out the decontaminating procedure at the customer's expense.

## 10.1 Packaging


<b>NOTICE</b>	
	<p><b>Valve in open position</b> Valve mechanism may get damaged if valve is in open position. Make sure that the valve is closed.</p>

1. Cover all valve openings with a protective foil.
2. Pack valve appropriately, by using the original packaging material.



VAT disclaims any liability for damages resulting from inappropriate packaging.

## 10.2 Transport

<b>NOTICE</b>	
	<p><b>Inappropriate packaging</b> Product may get damaged if inappropriate packaging material is used. Always use the original packaging material and handle product with care.</p>





VAT disclaims any liability for damages resulting from inappropriate packaging.





## 11 Disposal

Observe the local regulations for disposal

	<b>⚠ WARNING</b>
	<p><b>Harmful substances</b> Environmental pollution. Discard products and parts according to the local regulations.</p>

	<b>⚠ WARNING</b>
	<p><b>Unqualified personnel</b> Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the disposal.</p>

	<b>⚠ CAUTION</b>
	<p><b>Risk of damage</b> Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury. A large number of diverse materials are used in the product. Some of them could cause human and machine damage in the case of improper handling.</p> <ul style="list-style-type: none"> <li>• Observe local regulations in regard to waste disposal without fail.</li> <li>• Commission an authorized waste disposal company for the professional disposal of your waste.</li> </ul>

	<b>NOTICE</b>
	<p><b>Improper disposal</b> Some built-in materials can cause damage, if improperly handled. - When disposing, take into account all the different materials used</p>



- Hire an authorised waste disposal company to dispose of the waste in a professional manner.

The following list should help you to dismantle your product without making serious errors and to properly separate out the product scrap.

Material groups	Hazard level
non-ferrous metals	high
stainless steel	low
aluminum	low
plastics	medium
lubricants	high
electronic scrap	high
batteries	very high
cables and wires	medium
motors	medium
seals and rubber parts	high

## 12 Spare parts



### NOTICE

#### Non-original spare parts


Non-original spare parts may cause damage to the product.  
Use original spare parts from VAT only.



- Please specify the fabrication number of the product when you place an order for spare parts; see chapter: «Identification of product». This is to ensure that the appropriate spare parts are supplied.
- VAT makes a difference between spare parts that may be replaced by the customer and those that need to be replaced by the VAT service staff.
- The following table(s) contain spare parts that may be replaced by the customer. If you need any other spare parts, please contact one of our service centers. You will find the addresses on our website [www.vatvalve.com](http://www.vatvalve.com).

## 12.1 ISO-KF for DN 40 - 63mm

### 12.1.1 Drawing



- |   |                                  |   |               |
|---|----------------------------------|---|---------------|
| 1 | Body with mechanism              | 5 | Plate screws  |
| 2 | Lever complete                   | 6 | Body complete |
| 3 | Adapter flange, rod with bearing | 7 | Plate         |
| 4 | Rotary feedthrough seals         | 8 | Plate O-ring  |



All "Item" refer to chapter «Drawing»

**12.1.2 ISO-KF valve unit – aluminum hard anodized, without heating**

Item	Description		
	Valve size Product ordering number	DN 40 / 1½" 61632 - KH . . ISO-KF	DN 50 / 2" 61634 - KH . . ISO-KF
1	Spare parts kit body with mechanism	462173	453946
2	Spare parts kit lever complete	511515	
3	Spare parts kit, adapter flange rod with bearing	453094	453106
5	Plate screws	2 x 428946	
6	Body complete	443116	443180
8	Spare parts kit plate.	433800	431309

**12.1.3 ISO-KF valve unit – stainless steel, without heating**

Item	Description		
	Valve size Product ordering number	DN 40 / 1½" 61632 - KE . . ISO-KF	DN 50 / 2" 61634 - KE . . ISO-KF
1	Spare parts kit body with mechanism	462153	453945
2	Spare parts kit lever complete	511515	
3	Spare parts kit, adapter flange rod with bearing	453094	453106
5	Plate screws	2 x 428946	
6	Body complete	443048	443093
8	Spare parts kit plate.	428257	428118

#### 12.1.4 Seals and grease

Item	Description		
4	Vacuum seal kit (VITON ®) rotary feed through	237235	
	Vacuum grease (2ml syringe)	206792	
		<b>DN 40 / 1½"</b>	<b>DN 50 / 2"</b>
8	Vacuum seal kit (VITON ®) for plate	327291	365577





For versions such as:

- other valve sizes
- heated valves
- valves made of hard anodized aluminum
- valves made of nickel coated aluminum


spare parts ordering numbers are available on request.

#### 12.1.5 Clamping connections for ISO-KF

Valve size	Clamping chain	Clamping device
		
DN40 / 1½ "	31032-KASA-0001	31032-KASE-0001
DN50 / 2"	31034-KASA-0001	31034-KASE-0001

## 12.2 ISO-F for DN80 - 100mm

### 12.2.1 Drawing



Sample picture

- |   |                                  |   |               |
|---|----------------------------------|---|---------------|
| 1 | Body with mechanism              | 5 | Plate screws  |
| 2 | Lever complete                   | 6 | Body complete |
| 3 | Adapter flange, rod with bearing | 7 | Plate         |
| 4 | Rotary feedthrough seals         | 8 | Plate O-ring  |



All "Item" refer to chapter «Drawing»

### 12.2.2 ISO-F valve unit – aluminum hard anodized, without heating

Item	Valve size Product ordering number	Description		
		DN 63 / 2½" 61636 - PH . . . . .	DN 80 / 3" 61638 - PH . . . . .	DN 100 / 4" 61640 - PH . . . . .
1	Spare parts kit body with mechanism compl.	496935	497018	489207
2	Spare parts kit lever compl.	350045		
3	Spare parts kit shaft kit	471253	471254	471255
6	Body compl.	407250	449825	367045
7	Spare parts kit plate compl.	377974	377321	358337
	Plate screw (3pcs)	355662	361781	

### 12.2.3 ISO-F valve unit – stainless steel, without heating

Item	Valve size Product ordering number	Description		
		DN 63 / 2½" 61636 - PE . . . . .	DN 80 / 3" 61638 - PE . . . . .	DN 100 / 4" 61640 - PE . . . . .
1	Spare parts kit body with mechanism compl.	486575	497020	487017
2	Spare parts kit lever compl.	350045		
3	Spare parts kit shaft kit	471253	471254	471255
6	Body compl.	384963	394352	356034
7	Spare parts kit plate compl.	354547	363311	326557
	Plate screw (3 pcs)	355662	361781	

**12.2.4 Seals and grease**

Item	Description			
	Valve size	All sizes		
4	Rotary feed through seals (VITON ®) (2 pcs)	323642		
		<b>DN 63 / 2½"</b>	<b>DN 80 / 3"</b>	<b>DN 100 / 4"</b>
8	Plate seal (VITON ®)	380402	234889	365579
	Vacuum grease (4g syringe)	206792		
	Vacuum grease (10g syringe)	206793		



For versions such as:

- other valve sizes
- heated valves
- valves made of hard anodized aluminum
- valves made of nickel coated aluminum

spare parts ordering numbers are available on request.



## 12.3 Control unit and Accessories

### 12.3.1 Control and actuating unit

Description	Part number
Control and actuating unit	Too many to list. Please contact VAT.
Option board with SPS module (±15 VDC Sensor Power Supply)	858530
Option board with PFO module (Power Failure Option)	858529
Option board with SPS and PFO module	840512

### 12.3.2 Accessories

Description	Part number
24 VDC power supply unit (input: 100 – 240 VAC)	891528 (D-Sub15 connector)
Adapter cable for power supply with D-Sub9 connector	(735567) (D-Sub15 to D-Sub9)
Plug D-sub 15 pin female with 4-40UNC screws for the power input and Logic interface (plug only)	81177-R1
Service cable (PC to valve Service connector)	809474 (USB A–B male-male)
Special Allen wrench (SW3) for disassembly and assembly	244873
O-ring removal tool	234859

### 12.3.3 Centering ring with VITON® O-ring

Description		DN 40 / 1½"	DN 50 / 2"	DN 63 / 2½"	DN 80 / 3"	DN 100 / 4"
Valve size	Product ordering number					
Centering ring with VITON® O-ring (for ISO-KF and ISO-F installation only)	Aluminum	31032-KAZV	32036-QAZV	32038-QAZV	32040-QAZV	32040-QAZV
	Stainless steel	31032-KEZV	32036-QEZV	32038-QEZV	32040-QEZV	32040-QEZV

This page left blank intentionally.

